

WIFI IP CAMERA

Quick Manual fo Android and Ios

Power on

Connecting the device with power supply



Download the APP

Tips one:

You can scan the QR code install

Tips two:

You can search "icsee" in the mobile "App store" or "googleplay" and download.



iCsee APP

Open the app,choose the "login"

(If you don't have user name please temporary login)



Camera have two mode to visit:


1. AP Mode.
2. Router Mode.

Notice:

- 1,the method of change AP Mode and Router Mode:
Press triple reset button,(some model is press one second the reset button)
- 2.Restored to factory setting: long press the reset button for 6~8 seconds

1. AP Mode:

- 1.1 Click "+"




1.2 Choose "AP mode"



1.3 Choose the camera(camera or ipc)
Password : 1234567890
(some model no need password)



2. Router Mode:
2.1 Choose "Add My Device(recommended)"



2.2 Choose the name of you wifi and input wifi router password ,then confirm



2.3 After connect successfully,Enter to "set pwd", Then confirm.

