

Milesight Network Video Recorder Application Programming Interface.

CGI Specification

2018-10-23 V 1.0.7

Milesight Technology Co.,Ltd.

脉视数字技术有限公司

david@milesight.cn

Table of Contain

Table of Contain.....	2
Revision history.....	8
1.1 NETWORK.....	12
1.1.1 get.network.general.....	12
1.1.2 set.network.general.....	13
1.1.3 get.network.port.....	13
1.1.4 set.network.port.....	13
1.1.5 get.network.email.....	14
1.1.6 set.network.email.....	14
1.1.7 test.network.email.....	14
1.1.8 get.network.ddns.....	14
1.1.9 set.network.ddns.....	15
1.1.10 get.network.pppoe.....	15
1.1.11 set.network.pppoe.....	15
1.1.12 get.network.p2p.....	15
1.1.13 set.network.p2p.....	16
1.2 SYSTEM.....	16
1.2.1 get.system.time.....	16
1.2.2 set.system.time.....	16
1.2.3 get.system.sysstatus.....	16
1.2.4 get.system.sysinfo.....	16
1.2.5 set.system.reboot.....	17
1.2.6 set.system.devid.....	17
1.2.7 set.system.shutdown.....	17
1.3 USER.....	18
1.3.1 get.user.member.....	18
1.3.2 get.user.auth.....	18
1.3.3 get.user.count.....	18
1.3.4 set.user.member.....	19
1.3.5 add.user.member.....	19
1.3.6 del.user.member.....	19
1.4 EVENT.....	19
1.4.1 get.event.alarmin.....	19
1.4.2 set.event.alarmin.....	20
1.4.3 get.event.alarmout.....	20
1.4.4 set.event.alarmout.....	20
1.4.5 get.event.holidays.....	20
1.4.6 set.event.holidays.....	21
1.4.7 get.event.videoloss.....	21
1.4.8 set.event.videoloss.....	21
1.4.9 get.event.motion.....	21
1.4.10 set.event.motion.....	22

1.4.11 get.event.osd.....	22
1.4.12 set.event.osd.....	22
1.4.13 get.event.maintain_info.....	22
1.4.14 set.event.maintain_info.....	22
1.4.15 get.event.exception.....	22
1.4.16 set.event.exception.....	22
1.4.17 get.event.exception_info.....	23
1.5 SCHEDULE.....	23
1.5.1 get.schedule.recsched.....	23
1.5.2 set.schedule.recsched.....	23
1.5.3 get.schedule.motionsched.....	25
1.5.4 set.schedule.motionsched.....	25
1.5.5 get.schedule.videolosssched.....	30
1.5.6 set.schedule.videolosssched.....	31
1.5.7 get.schedule.alarminsched.....	32
1.5.8 set.schedule.alarminsched.....	33
1.5.9 get.schedule.alarmoutsched.....	34
1.5.10 set.schedule.alarmoutsched.....	34
1.5.11 get.schedule.motion_audible_sched.....	36
1.5.10 set.schedule.alarmoutsched.....	36
1.5.12 set.schedule.motion_audible_sched.....	36
1.5.13 get.schedule.motion_email_sched.....	38
1.5.10 set.schedule.alarmoutsched.....	38
1.5.14 set.schedule.motion_email_sched.....	38
1.5.15 get.schedule.motion_others.....	39
1.5.16 set.schedule.motion_others.....	40
1.5.17 get.schedule.videoloss_audible_sched.....	40
1.5.18 set.schedule.videoloss_audible_sched.....	40
1.5.19 get.schedule.videoloss_email_sched.....	41
1.5.20 set.schedule.videoloss_email_sched.....	42
1.5.21 set.schedule.videoloss_alarm_output.....	43
1.5.22 get.schedule.alarmin_audible_sched.....	43
1.5.23 set.schedule.alarmin_audible_sched.....	43
1.5.24 get.schedule.alarmin_email_sched.....	45
1.5.25 set.schedule.alarmin_email_sched.....	45
1.5.26 get.schedule.alarmin_ptz_sched.....	47
1.5.27 set.schedule.alarmin_ptz_sched.....	47
1.5.28 set.schedule.alarmin_alarm_output.....	49
1.5.29 get.schedule.motion_effective_sched.....	49
1.5.30 set.schedule.motion_effective_sched.....	49
1.5.31 get.schedule.vca_effective_sched.....	50
1.5.32 set.schedule.vca_effective_sched.....	51
1.5.33 get.schedule.vca_audible_sched.....	52
1.5.34 set.schedule.vca_audible_sched.....	53

1.5.35 get.schedule.vca_email_sched.....	54
1.5.36 set.schedule.vca_email_sched.....	54
1.5.37 get.schedule.vca_others.....	56
1.5.38 set.schedule.vca_others.....	56
1.6 PLAYBACK.....	56
1.6.1 get.playback.pbdayinfo.....	56
1.6.2 get.playback.recordinfo.....	56
1.6.3 get.playback.recordinfo_page.....	57
1.6.4 get.playback.remote.....	57
1.6.5 get.playback.jump.....	57
1.6.6 get.playback.jump_batch.....	58
1.6.7 get.playback.playtime.....	58
1.6.8 get.playback.rtspurl.....	58
1.6.9 set.playback.pause.....	58
1.6.10 set.playback.pause_batch.....	58
1.6.11 set.playback.snapshot.....	58
1.6.12 set.playback.snapshot_save.....	59
1.6.13 set.playback.resume.....	59
1.6.14 set.playback.start.....	59
1.6.15 set.playback.step.....	59
1.6.16 set.playback.step_batch.....	59
1.6.17 set.playback.stop.....	59
1.6.18 set.playback.stop_batch.....	59
1.6.19 set.playback.speed.....	59
1.6.20 set.playback.speed_batch.....	60
1.6.21 set.playback.close.....	60
1.6.22 set.playback.close_batch.....	60
1.7 CAMERA.....	60
1.7.1 get.camera.ipcparam.....	60
1.7.2 set.camera.ipcparam.....	61
1.7.3 get.camera.ipclist.....	61
1.7.4 add.camera.channel.....	62
1.7.5 modify.camera.channel.....	62
1.7.6 remove.camera.channel.....	62
1.7.7 get.camera.protocol.....	62
1.7.8 search.camera.chns.....	62
1.7.9 test.camera.ipconflict.....	63
1.7.10 test.camera.ipcconn.....	63
1.7.11 get.camera.rtsp.....	63
1.7.12 get.camera.imageparam.....	63
1.7.13 set.camera.imageparam.....	63
1.7.12 get.camera.imageparam.....	64
1.7.14 get.camera.privacy_mask.....	64
1.7.13 set.camera.imageparam.....	64

1.7.15 set.camera.privacy_mask.....	64
1.7.13 set.camera.imageparam.....	65
1.7.15 set.camera.privacy_mask.....	65
1.7.13 set.camera.imageparam.....	65
1.7.14 set.camera.privacy_mask.....	65
1.7.15 get.camera.privacy_mask.....	66
1.7.16 get.camera.ipctype.....	66
1.7.17 get.camera.osd.....	66
1.7.18 set.camera.osd.....	67
1.7.19 get.camera.vca.region.entarnce.....	67
1.7.20 set.camera.vca.region.entarnce.....	68
1.7.21 get.camera.vca.region.exiting.....	68
1.7.22 set.camera.vca.region.exiting.....	68
1.7.23 get.camera.vca.advanced.motion.....	68
1.7.24 set.camera.vca.advanced.motion.....	68
1.7.25 get.camera.vca.tamper.detection.....	68
1.7.26 set.camera.vca.tamper.detection.....	69
1.7.27 get.camera.vca.line.crossing.....	69
1.7.28 set.camera.vca.line.crossing.....	69
1.7.29 get.camera.vca.loitering.....	69
1.7.30 set.camera.vca.loitering.....	69
1.7.31 get.camera.vca.human.detection.....	70
1.7.32 set.camera.vca.human.detection.....	70
1.7.33 get.camera.vca.people.counting.....	70
1.7.34 set.camera.vca.people.counting.....	71
1.7.35 get.camera.vca.settings.....	71
1.7.36 set.camera.vca.settings.....	71
1.7.37 get.camera.vca.lisence.....	72
1.7.38 set.camera.vca.lisence.....	72
1.7.39 set.camera.vca.clearcount.....	72
1.7.40 get.camera.vca.support.....	72
1.7.41 get.camera.vca.support_all.....	72
1.7.42 get.camera.vca.person_point.....	72
1.8 STATUS.....	73
1.8.1 get.status.allipc.....	73
1.8.2 get.status.ipcinfo.....	73
1.8.3 get.status.ipcstatus.....	74
1.8.4 get.status.event.....	74
1.8.5 get.status.ioalarm.....	75
1.8.6 get.status.iosensor.....	75
1.8.7 get.status.netbandwidth.....	75
1.8.8 get.status.netinfo.....	75
1.8.9 get.status.netspeed.....	76
1.9 RECORD.....	76

1.9.1 get.record.advanced.....	76
1.9.2 set.record.advanced.....	77
1.9.3 set.record.record.....	77
1.9.4 set.record.mode.....	77
1.9.5 get.record.schedule.....	77
1.9.6 set.record.schedule.....	77
1.9.7 set.record.batchsetting.....	79
1.10 PTZ.....	79
1.10.1 set.ptz.auto_focus.....	79
1.10.2 set.ptz.auto_scan.....	79
1.10.3 set.ptz.brush_off.....	79
1.10.4 set.ptz.brush_on.....	79
1.10.5 set.ptz.down.....	80
1.10.5 set.ptz.focus_in.....	80
1.10.6 set.ptz.focus_out.....	80
1.10.7 set.ptz.focus_stop.....	80
1.10.8 get.ptz.serial_port.....	80
1.10.9 set.ptz.iris_minus.....	80
1.10.10 set.ptz.iris_plus.....	80
1.10.11 set.ptz.left.....	81
1.10.12 set.ptz.left_down.....	81
1.10.13 set.ptz.left_up.....	81
1.10.14 set.ptz.light_off.....	81
1.10.15 set.ptz.light_on.....	81
1.10.16 set.ptz.preset_clear.....	81
1.10.17 set.ptz.preset_goto.....	81
1.10.18 set.ptz.preset_set.....	81
1.10.19 set.ptz.right.....	81
1.10.20 set.ptz.right_down.....	82
1.10.21 set.ptz.right_up.....	82
1.10.22 set.ptz.serial_port.....	82
1.10.23 set.ptz.stop.....	82
1.10.24 set.ptz.tour_add.....	82
1.10.25 set.ptz.tour_clear.....	82
1.10.26 set.ptz.tour_delete.....	82
1.10.27 set.ptz.tour_down.....	82
1.10.28 set.ptz.tour_run.....	83
1.10.29 set.ptz.tour_stop.....	83
1.10.30 set.ptz.tour_up.....	83
1.10.31 set.ptz.up.....	83
1.10.32 set.ptz.zoom_in.....	83
1.10.33 set.ptz.zoom_out.....	83
1.11 DISK.....	83
1.11.1 set.disk.format.....	83

1.11.2 get.disk.storage_info.....	84
1.11.3 set.disk.storage_info.....	84
1.11.4 set.disk.property.....	84
1.11.5 set.disk.delete.....	85
1.11.6 set.disk.recycle_mode.....	85
1.11.7 get.disk.recycle_mode.....	85
1.12 QT.....	85
1.11.1 set.disk.format.....	85
1.11.3 set.disk.storage_info.....	85
1.11.2 get.disk.storage_info.....	85
1.11.2 get.disk.storage_info.....	86

Revision history

Revision	Date	Description	Author
Draft	2016/03/28	Draft version	david.milesight
V1. 0. 1	2016/12/19	Add remote_live_view_ex、 remote_playback_ex、 local_playback_ex、 local_live_view_ex、 tri_channels_ex Add control qt url Modify "add.camera.channel"	flycat milesight
V1. 0. 2	2017/05/10	get.status.motion get.system.sysinfo	david.milesight
V1. 0. 3	2017/10/26	set.schedule.motion_audible_sched get.schedule.motion_audible_sched set.schedule.motion_email_sched get.schedule.motion_email_sched set.schedule.motion_others get.schedule.motion_others set.schedule.videoloss_audible_sched get.schedule.videoloss_audible_sched set.schedule.videoloss_email_sched get.schedule.videoloss_email_sched set.schedule.videoloss_alarm_output set.schedule.alarmin_audible_sched get.schedule.alarmin_audible_sched set.schedule.alarmin_email_schedget. schedule.alarmin_email_sched set.schedule.alarmin_ptz_sched get.schedule.alarmin_ptz_sched set.schedule.alarmin_alarm_output set.camera.privacy_mask get.camera.privacy_mask set.record.batchsetting	yun.milesight

V1. 0. 4	2017/12/8	test.try.camera.ipcconn get.camera.ipcimage.enhance set.camera.ipcimage.enhance get.camera.ipcimage.display set.camera.ipcimage.display get.camera.all.modelinfo get.camera.fisheye.mode set.camera.fisheye.mode	flycat milesight
V1.0.5	2018/05/22	Update get.camera.ipcparam set.camera.ipcparam set.network.port get.network.port Add get.camera.ipctype get.camera.osd set.camera.osd get.network.p2p set.network.p2p	yun.milesight
V1.0.6	2018/10/15	Update get.playback.pbdayinfo get.playback.rtspurl set.playback.start set.playback.resume get.playback.playtime set.playback.speed get.disk.storage_info set.disk.format Add get.playback.recordinfo get.playback.recordinfo_page set.playback.pause_batch set.playback.jump_batch set.playback.step_batch set.playback.stop_batch	hrz.milesight

		set.playback.speed_batch set.playback.close set.playback.close_batch set.disk.property set.disk.delete	
V1.0.7	2018/10/23	Update set.schedule.motion_effective_sched set.schedule.motion_audible_sched set.schedule.motion_email_sched set.schedule.videoloss_audible_sched set.schedule.videoloss_email_sched set.schedule.alarmin_audible_sched set.schedule.alarmin_email_sched set.schedule.recsched get.status.event get.camera.rtsp get.record.advanced set.record.advanced Add get.camera.vca.region.entarnce set.camera.vca.region.entarnce get.camera.vca.region.exiting set.camera.vca.region.exiting get.camera.vca.advanced.motion set.camera.vca.advanced.motion get.camera.vca.tamper.detection set.camera.vca.tamper.detection get.camera.vca.line.crossing set.camera.vca.line.crossing get.camera.vca.loitering set.camera.vca.loitering get.camera.vca.human.detection set.camera.vca.human.detection get.camera.vca.people.counting set.camera.vca.people.counting	hrz.milesight

		get.camera.vca.settings set.camera.vca.settings get.camera.vca.lisence set.camera.vca.lisence set.camera.vca.clearcount get.camera.vca.support get.camera.vca.support_all get.camera.vca.person_point get.schedule.vca_effective_sched set.schedule.vca_effective_sched get.schedule.vca_audible_sched set.schedule.vca_audible_sched get.schedule.vca_email_sched set.schedule.vca_email_sched get.schedule.vca_others set.schedule.vca_others get.schedule.motion_effective_sched set.schedule.motion_effective_sched get.event.exception_info get.disk.recycle_mode set.disk.recycle_mode	
--	--	--	--

1.1 NETWORK

Parameter	Values	Description
mode	int	Working mode 0 : Multi-address 1 : Load Balance 2 : Net Fault-tolerance
host_name	String, max 128	Device name
miimon	int	
bond0_primary_net	int	
bond0_enable	int	Enable bond0 0 : No 1 : Yes
bond0_type	int	Bond type 0 : Static IP 1 : DHCP
bond0_ip_address	IP address	Bond0 ip
bond0_netmask	IP address	Bond0 netmask
bond0_gateway	IP address	Bond0 gateway
bond0_primary_dns	IP address	Bond0 primary DNS
bond0_second_dns	IP address	Bond0 second DNS
bond0_mtu	integer	Bond0 mtu
lan1_enable	Boolean	Enable lan1 0 : No 1 : Yes
lan1_type	Boolean	Lan1 type 0 : Static IP 1 : DHCP
lan1_ip_address	IP address	Lan1 ip
lan1_netmask	IP address	Lan1 netmask
lan1_gateway	IP address	Lan1 gateway
lan1_primary_dns	IP address	Lan1 primary dns
lan1_second_dns	IP address	Lan1 second dns
lan1_mtu	integer	Lan1 mtu
lan2_enable	Boolean	Enable lan2 0 : No

		1 : Yes
lan2_type	Boolean	Lan1 type 0 : Static IP 1 : DHCP
lan2_ip_address	IP address	Lan2 ip
lan2_netmask	IP address	Lan2 netmask
lan2_gateway	IP address	Lan2 gateway
lan2_primary_dns	IP address	Lan2 primary dns
lan2_second_dns	IP address	Lan2 second dns
lan2_mtu	integer	Lan2 mtu

Example: Get general parameter

<http://192.168.9.129/sdk.cgi?action=get.network.general>

To set general network parameters.

Example: Set general parameter

http://192.168.9.129/sdk.cgi?action=set.network.general&mode=0&host_name=NVR&bond0_primary_net=0&bond0_enable=1&bond0_type=1&bond0_ip_address=192.168.9.129&bond0_netmask=255.255.252.0&bond0_gateway=192.168.8.1&bond0_primary_dns=192.168.1.1&bond0_secondary_dns=&bond0_mtu=1500&lan1_enable=1&lan1_type=0&lan1_ip_address=192.168.9.129&lan1_netmask=255.255.252.0&lan1_gateway=192.168.8.1&lan1_primary_dns=8.8.8.8&lan1_secondary_dns=&lan1_mtu=1500&lan2_enable=0&lan2_type=0&lan2_ip_address=192.168.200.127&lan2_netmask=255.255.255.0&lan2_gateway=192.168.200.1&lan2_primary_dns=192.168.1.1&lan2_second_dns=&lan2_mtu=1500&lan1_dhcp_gateway=&lan2_dhcp_gateway=&tri_alarms=0

Parameter	Values	Description
enable_ssh	Boolean	Enable ssh 0 : disable 1 : enable
ssh_port	integer	SSH Port
http_port	integer	HTTP Port
rtsp_port	integer	RTSP Port
sdk_port	integer	SDK Port
url	String, max 12	URL
url_enable	Boolean	Enable url 0 : disable 1 : enable
enable_push	Boolean	Enable push 0 : disable 1 : enable
https_port	integer	HTTPS Port

Example: Get port parameter

<http://192.168.9.129/sdk.cgi?action=get.network.port>

To set port network parameters.

Example: Set port parameter

http://192.168.9.129/sdk.cgi?action=set.network.port&enable_ssh=1&ssh_port=22&http_port=

80&rtsp_port=554&sdk_port=1100&url=192.168.9.129&url_enable=1&enable_push=0&https_port=1111

Parameter	Values	Description
username	String, max 64	Email user name
password	String, max 64	Email password
smtp_server	String, max 64	Smtp server address
port	integer	Smtp port
sender_addr	String, max 128	Sender address
sender_name	String, max 64	Sender name
enable_tls	Boolean	Enable TLS 0 : disable 1 : enable
enable_attach	Boolean	Enable attach 0 : disable 1 : enable
capture_interval	integer	Capture interval
receiver_id0	integer	Receiver id
receiver_address0	String, max 128	Receiver address
receiver_name0	String, max 64	Receiver name
receiver_id1	integer	Receiver id
receiver_address1	String, max 128	Receiver address
receiver_name1	String, max 64	Receiver name
receiver_id2	integer	Receiver id
receiver_address2	String, max 128	Receiver address
receiver_name2	String, max 64	Receiver name

Example: Get general parameter

<http://192.168.9.129/sdk.cgi?action=get.network.email>

To set email network parameters.

Example: Set email parameter

http://192.168.9.129/sdk.cgi?action=set.network.email&username=david&password=hws8205&smtp_server=stmp.milesight.cn&port=25&sender_addr=david@milesight.cn&sender_name=david@milesight.cn&enable_tls=1&enable_attach=0&capture_interval=0&receiver_id0=0&receiver_address0=bug@milesight.cn&receiver_name0=bug@milesight.cn&receiver_id1=0&receiver_address1=&receiver_name1=&receiver_id2=0&receiver_address2=&receiver_name2=

To test email network parameters.

Example: test email parameter

<http://192.168.9.129/sdk.cgi?action=test.network.email>

Parameter	Values	Description
enable	Boolean	Enable DDNS 0 : disable 1 : enable
domain	String, max 64	DDNS domain
username	String, max 32	DDNS username

password	String, max 32	DDNS password
host_name	String, max 128	DDNS host name
free_dns_hash	String, max 128	DDNS hash
update_freq	integer	DDNS update frequency

Example: Get general parameter

<http://192.168.9.129/sdk.cgi?action=get.network.ddns>

To set ddns parameters.

Example: Set ddns parameter

http://192.168.9.129/sdk.cgi?action=set.network.ddns&enable=0&domain=dyndns.org&username=david&password=david&host_name=david&free_dns_hash=&update_freq=300

Parameter	Values	Description
enable	Boolean	Enable PPPoE 0 : disable 1 : enable
auto_connect	boolean	Auto connect 0 : disable 1 : enable
username	String, max 32	PPPoE username
password	String, max 32	PPPoE password

Example: Get general parameter

<http://192.168.9.129/sdk.cgi?action=get.network.pppoe>

To set pppoe parametes

Example: Set PPPoE parameter

http://192.168.9.129/sdk.cgi?action=set.network.pppoe&enable=0&auto_connect=0&username=david&password=milesgight

Parameter	Values	Description
enable	Boolean	Enable P2P 0 : disable 1 : enable
p2pstatus	integer	P2P Status 0:"OK" 1:"UNAUTH" 2:"NOTFOUND" 3:"NETWORK" 4:"UNKNOWN" 5:"MAC FORMAT" 6:"AUTH FAILED" 7:"NO UUID" 8:"P2P INIT FAILED" 9:"P2P LOGIN FAILED"

Example: Get general parameter

<http://192.168.9.129/sdk.cgi?action=get.network.p2p>

To set p2p status

Example: Set p2p status

<http://192.168.9.129/sdk.cgi?action=set.network.p2p&enableP2P=1>

1.2 SYSTEM

Parameter	Values	Description
ntp_enable	Boolean	Enable NTP 0 : disable 1 : enable
dst_enable	Boolean	Enable DST 0 : disable 1 : enable
time_zone	String, max 32	Time zone
time_zone_name	String, max 32	Time zone name
ntp_server	String, max 64	NTP server address
manual_time	String, max 32	Change current timestamp
time	Long	Change current timestamp

Example: Get system parameter

<http://192.168.9.129/sdk.cgi?action=get.system.time>

To set time parametes

Example: Set Time parametes

http://192.168.9.129/sdk.cgi?action=set.system.time&ntp_enable=0&dst_enable=0&time_zone=UTC-8&time_zone_name=CHN&ntp_server=pool.ntp.org&manual_time=2016-03-06 10:37:29&time=1459910249

Parameter	Values	Description
cpu	float	Cpu utilization
memory	integer	memory
usb	integer	usb
cpu_temperature	integer	Cpu temperature

Example: Get system parameter

<http://192.168.9.129/sdk.cgi?action=get.system.sysstatus>

Parameter	Values	Description
hostname	String max 128	Host name
deviceid	integer	Device ID
company	String max 10	Company name
productno	String max 10	Product NO
hardwareversion	String max 10	Hardware version
softwareversion	String max 10	Software version

<code>oemversion</code>		String max 10	OEM version
<code>devicetype</code>		String max 10	Device Type
<code>devicename</code>		String max 128	Device name
<code>sn</code>		String max 32	Serial number
<code>guistyle</code>		String max 10	GUI style
<code>reserve</code>		String max 10	reserve
resource	<code>rs_max_cameras</code>	integer	Max support camera numbers(4/8/16/32)
	<code>rs_max_analog_camer as</code>	integer	Max support analog camera numbers(0/4/8)
	<code>rs_max_ipnc_cameras</code>	integer	Max support IP network camera numbers
	<code>rs_camera_layout</code>	integer	
	<code>rs_display_num</code>	integer	Display screen number
	<code>rs_max_sensor</code>	integer	sensor 0~16
	<code>rs_max_alarm</code>	integer	Alarm 0~16
	<code>rs_hasBuzzer</code>	integer	Buzzer 0/1
	<code>rs_disk_num</code>	integer	Disk num 0~16
	<code>rs_max_dec_chan</code>	integer	Dec chn 0~16
	<code>rs_max_spot_out</code>	integer	Spot out 0~4
	<code>rs_max_audio_in</code>	integer	Audio in 0~16
	<code>rs_max_audio_out</code>	integer	Audio out
	<code>rs_max_network_lan</code>	integer	Network LAN number(1/2)
	<code>rs_max485</code>	Boolean	Enable 0 : disable 1 : enable
	<code>rs_max232</code>	boolean	Enable 0 : disable 1 : enable
	<code>rs_has_ir</code>	integer	IR
<code>uptime</code>		String max 32	Update time
<code>mac</code>		String max 32	eth0 mac

Example: Get system parameter

<http://192.168.9.129/sdk.cgi?action=get.system.sysinfo>

To set system reboot parametes

Example: set system reboot parametest

<http://192.168.9.129/sdk.cgi?action=set.system.reboot>

To set system devid parametes

Example: set system devid parametest

http://192.168.9.129/sdk.cgi?action=set.system.devid&device_id=110

To set system shutdown parametes

Example: set system shutdown parametest

<http://192.168.9.129/sdk.cgi?action=set.system.shutdown>

1.3 USER

Parameter	Values	Description
id	Integer 0~9	User id
enable	Boolean	Enable user 0 : disable 1 : enable
username	String, max 64	username
password	String, max 32	password
type	integer	User type 0 : admin 1 : operator 2 : viewer
permission	Integer 0~2>>31	Local permission
remote_permission	Integer 0~2>>31	Remote permission
local_live_view	unsigend long 0~2>>32	Local live view channel
local_playback	unsigend long 0~2>>32	Local playback channel
remote_live_view	unsigend long 0~2>>32	Remote live view channel
remote_playback	unsigend long 0~2>>32	Remote live view channel
local_live_view_ex	String, max 64	Local live view channel
local_playback_ex	String, max 64	Local playback channel
remote_live_view_ex	String, max 64	Remote live view channel
remote_playback_ex	String, max 64	Remote live view channel

Example: set user parametest

<http://192.168.9.129/sdk.cgi?action=get.user.member>

Parameter	Values	Description
ret	boolean	User auth result 0 : Yes 1 : No

Example: set user parametest

http://192.168.9.129/sdk.cgi?action=get.user.auth&auth_user=admin&auth_password=a395a6211f5604092e217750e78f72c4

Parameter	Values	Description
cnt	integer	User count

Example: set user parametest

<http://192.168.9.129/sdk.cgi?action=get.user.count>

To set user member parametes

Example: set user member

http://192.168.9.129/sdk.cgi?action=set.user.member&id=2&enable=1&username=david&password=a395a6211f5604092e217750e78f72c4&type=0&permission=-1&remote_permission=-1&local_live_view=0&local_playback=0&remote_live_view=5&remote_playback=5&local_live_view_ex=1010..&local_playback_ex=1010..&remote_live_view_ex=1010..&remote_playback_ex=1010..

To add user member parametes

Example: add user member

http://192.168.9.129/sdk.cgi?action=add.user.member&id=1&enable=1&username=david&password=a395a6211f5604092e217750e78f72c4&type=0&permission=-1&remote_permission=-1&local_live_view=0&local_playback=0&remote_live_view=0&remote_playback=0&local_live_view_ex=0000..&local_playback_ex=0000..&remote_live_view_ex=0000..&remote_playback_ex=0000..

To del user member parametes

Example: del user member

<http://192.168.9.129/sdk.cgi?action=del.user.member&userid=1>

1.4 EVENT

Parameter	Values	Description
id	Integer 0~15	Alarmin id
enable	integer	Enable alarmin 0 : Never 1 : Always 2 : By Schedule
name	String, max 128	Alarmin name
type	integer	Open status Type 0 : normally open 1 : normally closed
tri_channels	An unsigned integer 0~2<<32	trigger channels
tri_alarms	An unsigned integer 0~2<<32	trigger alarms
buzzer_interval	integer	
tri_channels_ex	String, max 64	trigger channels

Example: get event parametes

<http://192.168.9.129/sdk.cgi?action=get.event.alarmin&id=0>

To set event alarmin parametes

Example: set event alarmin

http://192.168.9.129/sdk.cgi?action=set.event.alarmin&id=0&enable=1&name=david&type=0&tri_channels=1&tri_alarms=17&buzzer_interval=20&tri_channels_ex=1000..

Parameter	Values	Description
id	Integer 0~3	Alarmout id
name	String max 128	Alarmout name
type	boolean	Alarmout type 0 : normally open 1 : normally closed
enable	boolean	Enable schedule 0 : Never 1 : Always 2 : By Schedule
duration_time	An unsigned integer	Duration time (s)

Example: get event parametes

<http://192.168.9.129/sdk.cgi?action=get.event.alarmout&id=0>

1.4.4 set.event.alarmout

To set event alarmin parametes

Example: set event alarmout

http://192.168.9.129/sdk.cgi?action=set.event.alarmout&id=0&enable=1&name=david&type=0&duration_time=5

Parameter	Values	Description
ch	Integer 0~31	Channel id
name	String max 256	Holidays name
enable	boolean	Enable holidays 0 : disable 1 : enable
type	integer	Holidays type 0 : By date 1 : By month 2 : By week
start_year	integer	Start year
start_mon	integer	Start month
start_mday	integer	Start day of a month
start_mweek	integer	Start week of a month
start_wday	integer	Start day of a week
end_year	integer	End year
end_mon	integer	End month
end_mday	integer	End day of a month

end_mweek	integer	End week of a month
end_wday	integer	End day of a week
tri_channels_ex	String, max 64	trigger channels

Example: get event parametes

<http://192.168.9.129/sdk.cgi?action=get.event.holidays>

To set event holidays parametes

Example: set event holidays

http://192.168.9.129/sdk.cgi?action=set.event.holidays&id=0&name=Holiday&enable=0&type=1&start_year=2013&start_mon=1&start_mday=1&start_mweek=1&start_wday=0&end_year=201&end_mon=1&end_mday=1&end_mweek=1&end_wday=0

Parameter	Values	Description
ch	integer	Channel id
enable	Integer 0 ~ 2	Enable schedule 0 : Never 1 : Always 2 : By Schedule
tri_alarms	An unsigned integer	Trigger alarm output mask

Example: get event parametes

<http://192.168.9.129/sdk.cgi?action=get.event.videoloss&id=0>

To set event voidloss parametes

Example: set event videoloss

http://192.168.9.129/sdk.cgi?action=set.event.videoloss&id=0&enable=1&tri_alarms=0

Parameter	Values	Description
ch	integer	Channel id
enable	boolean	Enable motion 0 : Never 1 : Always 2 : By Schedule
tri_channels	An unsigned integer	Trigger channels
tri_alarms	An unsigned integer	Trigger alarms
Motion_table	String max 356	Motion table
sensitivity	An unsigned integer	sensitivity
buzzer_sensitivity	An unsigned integer	buzzer_sensitivity
ipc_sched_enable	An unsigned integer	ipc_sched_enable
tri_channels_ex	String, max 64	Trigger channels

Example: get event parameters

<http://192.168.9.129/sdk.cgi?action=get.event.motion&id=0>

To set event voidloss parameters

Example: set event motion

Parameter	Values	Description
ch[i]	integer	Channel id
name[i]	String max 64	Osd name

Example: get event parameters

<http://192.168.9.129/sdk.cgi?action=get.event.osd>

To set event ptzinfo parameters

Example: set event osd parameters

<http://192.168.9.129/sdk.cgi?action=set.event.osd&id=0&name=david milesight>

Parameter	Values	Description
log	integer	Save log time (month)
photo	integer	Save photo time(month)

Example: get event parameters

http://192.168.9.129/sdk.cgi?action=get.event.maintain_info

To set event maintain info parameters

Example: set event maintain info parameters

http://192.168.9.129/sdk.cgi?action=set.event.maintain_info&log=6&photo=6

Parameter	Values	Description
network_disconn	integer	Network disconnected
disk_full	integer	HDD full
record_fail	integer	Record failed
disk_fail	integer	HDD failed

Example: get event parameters

<http://192.168.9.129/sdk.cgi?action=get.event.exception>

To set event exception parameters

Example: set event exception parameters

http://192.168.9.129/sdk.cgi?action=set.event.exception&network_disconn=0&disk_full=0&reco_rd_fail=0&disk_fail=1

Parameter	Values	Description
cnt	integer	Exception information count
event	string	Event
information	string	Information

Example: get event exception information

http://192.168.9.129/sdk.cgi?action=get.event.exception_info

1.5 SCHEDULE

Parameter		Values	Description	
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer] Wholeday_enable : 0/1 [integer] Wholeday_action_type : wholeday action type [integer]	
		end_time		
		action_type		
	wholeday_enable			
	wholeday_action_type			
enable		integer	~	
ch		integer	Channel id	

Example: get schedule parameters

<http://192.168.9.129/sdk.cgi?action=get.schedule.recsched&ch=0>

To set schedule recsched parameters

Example: set schedule recsched parameters

ction_type[1][0]=0&start_time[1][1]=&end_time[1][1]=&action_type[1][1]=0&start_time[1][2]=&end_time[1][2]=&action_type[1][2]=0&start_time[1][3]=&end_time[1][3]=&action_type[1][3]=0&start_time[1][4]=&end_time[1][4]=&action_type[1][4]=0&start_time[1][5]=&end_time[1][5]=&action_type[1][5]=0&start_time[1][6]=&end_time[1][6]=&action_type[1][6]=0&start_time[1][7]=&end_time[1][7]=&action_type[1][7]=0&start_time[1][8]=&end_time[1][8]=&action_type[1][8]=0&start_time[1][9]=&end_time[1][9]=&action_type[1][9]=0&start_time[1][10]=&end_time[1][1]0=&action_type[1][10]=0&start_time[1][11]=&end_time[1][11]=&action_type[1][11]=0&wholeday_enable[2]=0&wholeday_action_type[2]=0&start_time[2][0]=&end_time[2][0]=&action_type[2][0]=0&start_time[2][1]=&end_time[2][1]=&action_type[2][1]=0&start_time[2][2]=&end_time[2][2]=&action_type[2][2]=0&start_time[2][3]=&end_time[2][3]=&action_type[2][3]=0&start_time[2][4]=&end_time[2][4]=&action_type[2][4]=0&start_time[2][5]=&end_time[2][5]=&action_type[2][5]=0&start_time[2][6]=&end_time[2][6]=&action_type[2][6]=0&start_time[2][7]=&end_time[2][7]=&action_type[2][7]=0&start_time[2][8]=&end_time[2][8]=&action_type[2][8]=0&start_time[2][9]=&end_time[2][9]=&action_type[2][9]=0&start_time[2][10]=&end_time[2][10]=&action_type[2][10]=0&start_time[2][11]=&end_time[2][11]=&action_type[2][11]=0&wholeday_enable[3]=0&wholeday_action_type[3]=0&start_time[3][0]=&end_time[3][0]=&action_type[3][0]=0&start_time[3][1]=&end_time[3][1]=&action_type[3][1]=0&start_time[3][2]=&end_time[3][2]=&action_type[3][2]=0&start_time[3][3]=&end_time[3][3]=&action_type[3][3]=0&start_time[3][4]=&end_time[3][4]=&action_type[3][4]=0&start_time[3][5]=&end_time[3][5]=&action_type[3][5]=0&start_time[3][6]=&end_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=&action_type[3][7]=0&start_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]=&end_time[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&start_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&wholeday_enable[4]=0&wholeday_action_type[4]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4][4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4][5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]=0&wholeday_enable[5]=0&wholeday_action_type[5]=0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&action_type[5][11]=0&wholeday_enable[6]=0&wholeday_action_type[6]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]

```
=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]
=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[
6][11]=&action_type[6][11]=0&wholeday_enable[7]=0&wholeday_action_type[7]=0&start_time[
7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[
7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[
7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_tim
e[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_typ
e[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_tim
e[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_ti
me[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&act
ion_type[7][11]=0
```

Parameter		Values	Description	
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer] Wholeday_enable : 0/1 [integer] Wholeday_action_type : wholeday action type [integer]	
		end_time		
		action_type		
	wholeday_enable			
	wholeday_action_type			
id		integer	Channel id	
copy_channel		String 64	0: not need to copy 1: need to copy	

Example: get schedule parameters

<http://192.168.9.129/sdk.cgi?action=get.schedule.motionsched&ch=0>

To set schedule motionsched parameters

Example: set schedule motionsched parameters

7][5]=&end_time_audible[7][5]=&action_type_audible[7][5]=0&start_time_audible[7][6]=&end_time_audible[7][6]=&action_type_audible[7][6]=0&start_time_audible[7][7]=&end_time_audible[7][7]=&action_type_audible[7][7]=0&start_time_audible[7][8]=&end_time_audible[7][8]=&action_type_audible[7][8]=0&start_time_audible[7][9]=&end_time_audible[7][9]=&action_type_audible[7][9]=0&start_time_audible[7][10]=&end_time_audible[7][10]=&action_type_audible[7][10]=0&start_time_audible[7][11]=&end_time_audible[7][11]=&action_type_audible[7][11]=0&email_enable=0&email_interval=60&start_time_email[0][0]=00:00&end_time_email[0][0]=24:00&action_type_email[0][0]=8&start_time_email[0][1]=00:00&end_time_email[0][1]=00:00&action_type_email[0][1]=2&start_time_email[0][2]=&end_time_email[0][2]=&action_type_email[0][2]=2&start_time_email[0][3]=&end_time_email[0][3]=&action_type_email[0][3]=0&start_time_email[0][4]=&end_time_email[0][4]=&action_type_email[0][4]=0&start_time_email[0][5]=&end_time_email[0][5]=&action_type_email[0][5]=0&start_time_email[0][6]=&end_time_email[0][6]=&action_type_email[0][6]=0&start_time_email[0][7]=&end_time_email[0][7]=&action_type_email[0][7]=0&start_time_email[0][8]=&end_time_email[0][8]=&action_type_email[0][8]=0&start_time_email[0][9]=&end_time_email[0][9]=&action_type_email[0][9]=0&start_time_email[0][10]=&end_time_email[0][10]=&action_type_email[0][10]=0&start_time_email[0][11]=12:00&end_time_email[0][11]=14:00&action_type_email[0][11]=2&start_time_email[1][0]=&end_time_email[1][0]=&action_type_email[1][0]=0&start_time_email[1][1]=&end_time_email[1][1]=&action_type_email[1][1]=0&start_time_email[1][2]=&end_time_email[1][2]=&action_type_email[1][2]=0&start_time_email[1][3]=&end_time_email[1][3]=&action_type_email[1][3]=0&start_time_email[1][4]=&end_time_email[1][4]=&action_type_email[1][4]=0&start_time_email[1][5]=&end_time_email[1][5]=&action_type_email[1][5]=0&start_time_email[1][6]=&end_time_email[1][6]=&action_type_email[1][6]=0&start_time_email[1][7]=&end_time_email[1][7]=&action_type_email[1][7]=0&start_time_email[1][8]=&end_time_email[1][8]=&action_type_email[1][8]=0&start_time_email[1][9]=&end_time_email[1][9]=&action_type_email[1][9]=0&start_time_email[1][10]=&end_time_email[1][10]=&action_type_email[1][10]=0&start_time_email[1][11]=&end_time_email[1][11]=&action_type_email[1][11]=0&start_time_email[2][0]=&end_time_email[2][0]=&action_type_email[2][0]=0&start_time_email[2][1]=&end_time_email[2][1]=&action_type_email[2][1]=0&start_time_email[2][2]=&end_time_email[2][2]=&action_type_email[2][2]=0&start_time_email[2][3]=&end_time_email[2][3]=&action_type_email[2][3]=0&start_time_email[2][4]=&end_time_email[2][4]=&action_type_email[2][4]=0&start_time_email[2][5]=&end_time_email[2][5]=&action_type_email[2][5]=0&start_time_email[2][6]=&end_time_email[2][6]=&action_type_email[2][6]=0&start_time_email[2][7]=&end_time_email[2][7]=&action_type_email[2][7]=0&start_time_email[2][8]=&end_time_email[2][8]=&action_type_email[2][8]=0&start_time_email[2][9]=&end_time_email[2][9]=&action_type_email[2][9]=0&start_time_email[2][10]=&end_time_email[2][10]=&action_type_email[2][10]=0&start_time_email[2][11]=&end_time_email[2][11]=&action_type_email[2][11]=0&start_time_email[3][0]=&end_time_email[3][0]=&action_type_email[3][0]=0&start_time_email[3][1]=&end_time_email[3][1]=&action_type_email[3][1]=0&start_time_email[3][2]=&end_time_email[3][2]=&action_type_email[3][2]=0&start_time_email[3][3]=&end_time_email[3][3]=&action_type_email[3][3]=0&start_time_email[3][4]=&end_time_email[3][4]=&action_type_email[3][4]=0&start_time_email[3][5]=&end_time_email[3][5]=&action_type_email[3][5]=0&start_time_email[3][6]=&end_time_email[3][6]=&action_type_email[3][6]=0&start_time_email[3][7]=&end_time_email[3][7]=&action_type_email[3][7]=0&start_time_email[3][8]=&end_time_email[3][8]=&action_type_email[3][8]=0&start_time_email[3][9]

Parameter	Values	Description
-----------	--------	-------------



8xschedule_day	12xschedule_item	start_time	struct	start_time : start rec time [char [32]]	
		end_time		end_time : end rec time [char [32]]	
		action_type		action_type : rec type [integer]	
	wholeday_enable			Wholeday_enable : 0/1 [integer]	
	wholeday_action_type			Wholeday_action_type : wholeday action type [integer]	
id	integer	Channel id			

Example: get schedule parameters

<http://192.168.9.129/sdk.cgi?action=get.schedule.videolosssched&ch=0>

To set schedule videotlosssched parameters

Example: set schedule videotlossched parameters

```

e[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&star
t_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&wholeday_enable[4]=0&wholeday_act
ion_type[4]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][0]=0&start_time[4][1]=&end
_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][2]=&action_type[4][2]=0&sta
rt_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4][4]=&end_time[4][4]=&actio
n_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4][5]=0&start_time[4][6]=&en
d_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&st
art_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&acti
on_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[4][11]
=&end_time[4][11]=&action_type[4][11]=0&wholeday_enable[5]=0&wholeday_action_type[5]=
0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=
&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]
=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]
=0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]
=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][
8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][
9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_tim
e[5][11]=&action_type[5][11]=0&wholeday_enable[6]=0&wholeday_action_type[6]=0&start_tim
e[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_typ
e[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_tim
e[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_t
ime[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_t
ype[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_t
ime[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start
_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&
action_type[6][11]=0&wholeday_enable[7]=0&wholeday_action_type[7]=0&start_time[7][0]=&e
nd_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&
start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&a
ction_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=
&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=
0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=
&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][1
0]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_t
ype[7][11]=0

```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer] Wholeday_enable : 0/1 [integer] Wholeday_action_type : wholeday action type [integer]
		end_time	
		action_type	
	wholeday_enable		
	wholeday_action_type		
id		integer	Channel id

Example: get schedule parameters



<http://192.168.9.129/sdk.cgi?action=get.schedule.alarmsched&ch=0>

To set schedule alarmsched parameters

Example: set schedule alrmminsched parameters

```

on_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[4][11]
=&end_time[4][11]=&action_type[4][11]=0&wholeday_enable[5]=0&wholeday_action_type[5]=
0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=
&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]
=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]
=0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]
=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][
8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][
9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_tim
e[5][11]=&action_type[5][11]=0&wholeday_enable[6]=0&wholeday_action_type[6]=0&start_tim
e[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_typ
e[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_tim
e[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_t
ime[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_t
ype[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_t
ime[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_
time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&
action_type[6][11]=0&wholeday_enable[7]=0&wholeday_action_type[7]=0&start_time[7][0]=&e
nd_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&
start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&a
ction_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=
&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=
0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=
&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][1
0]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_t
ype[7][11]=0

```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer] Wholeday_enable : 0/1 [integer] Wholeday_action_type : wholeday action type [integer]
		end_time	
		action_type	
	wholeday_enable	wholeday_enable	
		wholeday_action_type	
id		integer	Channel id

Example: get schedule parametes

<http://192.168.9.129/sdk.cgi?action=get.schedule.alarmoutsched&ch=0>

To set schedule alarmoutsched parametes

Example: set schedule alrmoutsched parametes

[http://192.168.9.129/sdk.cgi?action=set.schedule.alarmoutsched&ch=0&wholeday_enable\[0\]=1&wholeday_action_type\[0\]=1&start_time\[0\]\[0\]=00:00&end_time\[0\]\[0\]=01:00&action_type\[0\]\[0\]=0&start_time\[0\]\[1\]=00:00&end_time\[0\]\[1\]=12:00&action_type\[0\]\[1\]=1&start_time\[0\]\[2\]=&end](http://192.168.9.129/sdk.cgi?action=set.schedule.alarmoutsched&ch=0&wholeday_enable[0]=1&wholeday_action_type[0]=1&start_time[0][0]=00:00&end_time[0][0]=01:00&action_type[0][0]=0&start_time[0][1]=00:00&end_time[0][1]=12:00&action_type[0][1]=1&start_time[0][2]=&end)

```
_time[0][2]=&action_type[0][2]=0&start_time[0][3]=&end_time[0][3]=&action_type[0][3]=0&sta
rt_time[0][4]=&end_time[0][4]=&action_type[0][4]=0&start_time[0][5]=&end_time[0][5]=&actio
n_type[0][5]=0&start_time[0][6]=&end_time[0][6]=&action_type[0][6]=0&start_time[0][7]=&en
d_time[0][7]=&action_type[0][7]=0&start_time[0][8]=&end_time[0][8]=&action_type[0][8]=0&st
art_time[0][9]=&end_time[0][9]=&action_type[0][9]=0&start_time[0][10]=&end_time[0][10]=&a
ction_type[0][10]=0&start_time[0][11]=12:00&end_time[0][11]=14:00&action_type[0][11]=2&w
holeday_enable[1]=0&wholeday_action_type[1]=0&start_time[1][0]=&end_time[1][0]=&action_
type[1][0]=0&start_time[1][1]=&end_time[1][1]=&action_type[1][1]=0&start_time[1][2]=&end_t
ime[1][2]=&action_type[1][2]=0&start_time[1][3]=&end_time[1][3]=&action_type[1][3]=0&start
_time[1][4]=&end_time[1][4]=&action_type[1][4]=0&start_time[1][5]=&end_time[1][5]=&action
_type[1][5]=0&start_time[1][6]=&end_time[1][6]=&action_type[1][6]=0&start_time[1][7]=&end
_time[1][7]=&action_type[1][7]=0&start_time[1][8]=&end_time[1][8]=&action_type[1][8]=0&sta
rt_time[1][9]=&end_time[1][9]=&action_type[1][9]=0&start_time[1][10]=&end_time[1][10]=&ac
tion_type[1][10]=0&start_time[1][11]=&end_time[1][11]=&action_type[1][11]=0&wholeday_ene
able[2]=0&wholeday_action_type[2]=0&start_time[2][0]=&end_time[2][0]=&action_type[2][0]=0
&start_time[2][1]=&end_time[2][1]=&action_type[2][1]=0&start_time[2][2]=&end_time[2][2]=&
action_type[2][2]=0&start_time[2][3]=&end_time[2][3]=&action_type[2][3]=0&start_time[2][4]=
&end_time[2][4]=&action_type[2][4]=0&start_time[2][5]=&end_time[2][5]=&action_type[2][5]=
0&start_time[2][6]=&end_time[2][6]=&action_type[2][6]=0&start_time[2][7]=&end_time[2][7]=
&action_type[2][7]=0&start_time[2][8]=&end_time[2][8]=&action_type[2][8]=0&start_time[2][9]
=&end_time[2][9]=&action_type[2][9]=0&start_time[2][10]=&end_time[2][10]=&action_type[2][
10]=0&start_time[2][11]=&end_time[2][11]=&action_type[2][11]=0&wholeday_enable[3]=0&wh
oleday_action_type[3]=0&start_time[3][0]=&end_time[3][0]=&action_type[3][0]=0&start_time[
3][1]=&end_time[3][1]=&action_type[3][1]=0&start_time[3][2]=&end_time[3][2]=&action_type[
3][2]=0&start_time[3][3]=&end_time[3][3]=&action_type[3][3]=0&start_time[3][4]=&end_time[
3][4]=&action_type[3][4]=0&start_time[3][5]=&end_time[3][5]=&action_type[3][5]=0&start_t
ime[3][6]=&end_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=&action_t
ype[3][7]=0&start_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]=&end_t
ime[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&star
t_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&wholeday_enable[4]=0&wholeday_act
ion_type[4]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][0]=0&start_time[4][1]=&end
_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][2]=&action_type[4][2]=0&sta
rt_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4][4]=&end_time[4][4]=&actio
n_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4][5]=0&start_time[4][6]=&en
d_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&st
art_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&acti
on_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[4][11]
=&end_time[4][11]=&action_type[4][11]=0&wholeday_enable[5]=0&wholeday_action_type[5]=
0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=
&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]
=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=
0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]
=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][
8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][
```

```
9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&action_type[5][11]=0&wholeday_enable[6]=0&wholeday_action_type[6]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&wholeday_enable[7]=0&wholeday_action_type[7]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch			integer Channel id

Example: get schedule parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.motion audible_sched&ch=0

To set schedule motion audible sched parametes

Example: set schedule motion audible sched parameters


```
[6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id

Example: get schedule parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.motion_email_sched&ch=0

To set schedule motion_email_sched parameters

Example: set schedule motion_email_sched parameters

```
[5]=0&start_time[3][6]=&end_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=&action_type[3][7]=0&start_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]=&end_time[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&start_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4][4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4][5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]=0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&action_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter	Values	Description
type	integer	triAlarms:2 triChannels:1
ch	integer	Channel id
triAlarms	integer	triAlarms:Alarm Input rec
triChannels	char	triChannels:Trigger Channel rec [char [64]]

Example: get others parametes

http://192.168.9.147/sdk.cgi?action=get.schedule.motion_others&ch=0

To set schedule motion_others parametes

Example: set schedule motion_others parametes

http://192.168.9.147/sdk.cgi?action=set.schedule.motion_others&type=2&ch=0&triAlarms=63

http://192.168.9.147/sdk.cgi?action=set.schedule.motion_others&type=1&ch=0&triChannels=11111111111111111111111111111111

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id

Example: get schedule parameters

<http://192.168.9.147/sdk.cgi?action=get.schedule.videoloss audible sched&ch=0>

To set schedule `videoloss audible_sched` parameters

Example: set schedule videotloss_audible_sched parametes

```

ction_type[3][2]=0&start_time[3][3]=&end_time[3][3]=&action_type[3][3]=0&start_time[3][4]=
&end_time[3][4]=&action_type[3][4]=0&start_time[3][5]=&end_time[3][5]=&action_type[3][5]=
0&start_time[3][6]=&end_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=
&action_type[3][7]=0&start_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]
=&end_time[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][
10]=0&start_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&start_time[4][0]=&end_tim
e[4][0]=&action_type[4][0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_t
ime[4][2]=&end_time[4][2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_t
ype[4][3]=0&start_time[4][4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_t
ime[4][5]=&action_type[4][5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start
_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action
_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&en
d_time[4][10]=&action_type[4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]
=0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]
=&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][
3]=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][
4]=0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][
6]=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5]
[8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5]
[9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_t
ime[5][11]=&action_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&sta
rt_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&actio
n_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&en
d_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&st
art_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&acti
on_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&e
nd_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]
=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7]
[0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[
7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[
7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[
7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_t
ime[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_t
ype[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_t
ime[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0

```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id
copy_channel		string 64	0: not need to copy 1: need to copy

Example: get schedule parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.videoloss_email_sched&ch=0

To set schedule videotoss_email_sched parameters

Example: set schedule videotoss_email_sched parameters

```

me[4][10]=&action_type[4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]=0
&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&
action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=
&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=0
&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=
&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=
=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0
&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=
&action_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=
=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0
&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=
&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=
=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0
&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=
&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0
&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=
=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=
=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0
&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=
&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=
=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0
&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=
&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0

```

Parameter	Values	Description
ch	integer	Channel id
triAlarms	integer	triAlarms:Alarm Input rec

To set schedule videoloss_alarm_output parametes

Example: set schedule videoloss_alarm_output parametes

http://192.168.9.147/sdk.cgi?action=set.schedule.videoloss_alarm_output&ch=0&triAlarms=63

Parameter		Values	Description	
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]	
		end_time		
		action_type		
ch		integer	Channel id	
copy_channel		String 64	0: not need to copy 1: need to copy	

Example: get schedule parametes

http://192.168.9.147/sdk.cgi?action=get.schedule.alarmin_audible_sched&ch=0

To set schedule alarmin_audible_sched parametes

Example: set schedule alarmin_audible_sched parametes

&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&action_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id
copy_channel		String 64	0: not need to copy 1: need to copy

Example: get schedule parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.alarmin_email_sched&ch=0

To set schedule alarmin_email_sched parameters

Example: set schedule alarmin_email_sched parameters


```

2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][
3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][
5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7]
[7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7]
[8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7]
[10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0

```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id
copy_channel		String 64	0: not need to copy 1: need to copy

Example: get schedule parametes

http://192.168.9.147/sdk.cgi?action=get.schedule.alarmin_ptz_sched&ch=0

To set schedule alarmin_ptz_sched parametes

Example: set schedule alarmin_ptz_sched parametes

[第 47 页](http://192.168.9.147/sdk.cgi?action=set.schedule.alarmin_ptz_sched&ch=2&acto_ptz_channel=2&acto_ptz_preset_enable=1&acto_ptz_preset=1&acto_ptz_patrol_enable=0&acto_ptz_patrol=0&start_time[0][0]=00:00&end_time[0][0]=01:00&action_type[0][0]=0&start_time[0][1]=00:00&end_time[0][1]=12:00&action_type[0][1]=6&start_time[0][2]=&end_time[0][2]=&action_type[0][2]=6&start_time[0][3]=&end_time[0][3]=&action_type[0][3]=6&start_time[0][4]=&end_time[0][4]=&action_type[0][4]=6&start_time[0][5]=&end_time[0][5]=&action_type[0][5]=0&start_time[0][6]=&end_time[0][6]=&action_type[0][6]=0&start_time[0][7]=&end_time[0][7]=&action_type[0][7]=0&start_time[0][8]=&end_time[0][8]=&action_type[0][8]=0&start_time[0][9]=&end_time[0][9]=&action_type[0][9]=0&start_time[0][10]=&end_time[0][10]=&action_type[0][10]=0&start_time[0][11]=12:00&end_time[0][11]=14:00&action_type[0][11]=6&start_time[1][0]=&end_time[1][0]=&action_type[1][0]=0&start_time[1][1]=&end_time[1][1]=&action_type[1][1]=0&start_time[1][2]=&end_time[1][2]=&action_type[1][2]=0&start_time[1][3]=&end_time[1][3]=&action_type[1][3]=0&start_time[1][4]=&end_time[1][4]=&action_type[1][4]=0&start_time[1][5]=&end_time[1][5]=&action_type[1][5]=0&start_time[1][6]=&end_time[1][6]=&action_type[1][6]=0&start_time[1][7]=&end_time[1][7]=&action_type[1][7]=0&start_time[1][8]=&end_time[1][8]=&action_type[1][8]=0&start_time[1][9]=&end_time[1][9]=&action_type[1][9]=0&start_time[1][10]=&end_time[1][10]=&action_type[1][10]=0&start_time[1][11]=&end_time[1][11]=&action_type[1][11]=0&start_time[2][0]=&end_time[2][0]=&action_type[2][0]=0&start_time[2][1]=&end_time[2][1]=&action_type[2][1]=0&start_time[2][2]=&end_time[2][2]=&action_type[2][2]=0&start_time[2][3]=&end_time[2][3]=&action_type[2][3]=0&start_time[2][4]=&end_time[2][4]=&action_type[2][4]=0&start_time[2][5]=&end_time[2][5]=&action_type[2][5]=0&start_time[2][6]=&end_time[2][6]=&action_type[2][6]=0&start_time[2][7]=&end_time[2][7]=&action_type[2][7]=0&start_time[2][8]=&end_time[2][8]=&action_type[2][8]=0&start_time[2][9]=&end_time[2][9]=&action_type[2][9]
</p>
</div>
<div data-bbox=)

```
=0&start_time[2][10]=&end_time[2][10]=&action_type[2][10]=0&start_time[2][11]=&end_time[2][11]=&action_type[2][11]=0&start_time[3][0]=&end_time[3][0]=&action_type[3][0]=0&start_time[3][1]=&end_time[3][1]=&action_type[3][1]=0&start_time[3][2]=&end_time[3][2]=&action_type[3][2]=0&start_time[3][3]=&end_time[3][3]=&action_type[3][3]=0&start_time[3][4]=&end_time[3][4]=&action_type[3][4]=0&start_time[3][5]=&end_time[3][5]=&action_type[3][5]=0&start_time[3][6]=&end_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=&action_type[3][7]=0&start_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]=&end_time[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&start_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4][4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4][5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]=0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&action_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter	Values	Description
type	integer	triAlarms:1 triChannels:0
ch	integer	Channel id
triAlarms	integer	triAlarms:Alarm Input rec
triChannels	char	triChannels:Trigger Channel rec [char [64]]

To set schedule alarmin_alarm_output parameters

Example: set schedule alarmin alarm output parametes

http://192.168.9.147/sdk.cgi?action=set.schedule.alarmin_alarm_output&ch=0&triAlarms=63&type=1

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id
copy_channel		String 64	0: not need to copy 1: need to copy

Example: get schedule parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.motion_effective_sched&ch=0

```
[10]=&end_time[2][10]=&action_type[2][10]=0&start_time[2][11]=&end_time[2][11]=&action_t
ype[2][11]=0&start_time[3][0]=&end_time[3][0]=&action_type[3][0]=0&start_time[3][1]=&end_
time[3][1]=&action_type[3][1]=0&start_time[3][2]=&end_time[3][2]=&action_type[3][2]=0&star
t_time[3][3]=&end_time[3][3]=&action_type[3][3]=0&start_time[3][4]=&end_time[3][4]=&actio
n_type[3][4]=0&start_time[3][5]=&end_time[3][5]=&action_type[3][5]=0&start_time[3][6]=&en
d_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=&action_type[3][7]=0&st
art_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]=&end_time[3][9]=&acti
on_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&start_time[3][11]
=&end_time[3][11]=&action_type[3][11]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][
0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][
2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4]
[4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4]
[5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][
7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4]
[9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[
4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]=0&start_time[5][0]=&end_t
ime[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&action_type[5][1]=0&start
_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=&end_time[5][3]=&action
_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=0&start_time[5][5]=&end
_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=&action_type[5][6]=0&sta
rt_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=&end_time[5][8]=&actio
n_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0&start_time[5][10]=&e
nd_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&action_type[5][1
1]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][
1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6]
[3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6]
[4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][
6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6]
[8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6]
[9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_ti
me[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&sta
rt_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&actio
n_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&en
d_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&st
art_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&acti
on_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&e
nd_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]
=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	



ch	integer	Channel id
event	integer	Smart event type 0:region entarnce 1:region exiting 2:advanced.motion detection 3:tamper detection 4:line crossing 5:loitering 6:human detection 7:people counting

Example: get schedule parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.vca_effective_sched&ch=0&event=0

Example: set schedule vca effective sched parametes

```

n_type[4][0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&en
d_time[4][2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&st
art_time[4][4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&acti
on_type[4][5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&e
nd_time[4][7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&
start_time[4][9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&end_time[4][10]=
&action_type[4][10]=0&start_time[4][11]=&end_time[4][11]=&action_type[4][11]=0&start_time
[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&action_type
[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=&end_time[
5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=0&start_tim
e[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=&action_typ
e[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]=&end_tim
e[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]=0&start_t
ime[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[5][11]=&act
ion_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&
end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0
&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&
action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=
&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=
0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=
&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[
6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=&action_ty
pe[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_t
ime[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start
_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action
_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end
_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&sta
rt_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&ac
tion_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0

```

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer]
		end_time	
		action_type	
ch		integer	Channel id
event		integer	Smart event type 0:region entarnce 1:region exiting 2:advanced.motion detection 3:tamper detection 4:line crossing 5:loitering 6:human detection 7:people counting
interval		integer	Triggered Interval(s)

Example: get schedule parametes

http://192.168.9.147/sdk.cgi?action=get.schedule.vca_audible_sched&ch=0&event=0

Example: set schedule vca audible sched parameters

[第 53 页](http://192.168.9.147/sdk.cgi?action=set.schedule.vca_audible_sched&ch=0&event=0&interval=20&&start_time[0][0]=00:00&end_time[0][0]=24:00&action_type[0][0]=8&start_time[0][1]=00:00&end_time[0][1]=12:00&action_type[0][1]=1&start_time[0][2]=&end_time[0][2]=&action_type[0][2]=0&start_time[0][3]=&end_time[0][3]=&action_type[0][3]=0&start_time[0][4]=&end_time[0][4]=&action_type[0][4]=0&start_time[0][5]=&end_time[0][5]=&action_type[0][5]=0&start_time[0][6]=&end_time[0][6]=&action_type[0][6]=0&start_time[0][7]=&end_time[0][7]=&action_type[0][7]=0&start_time[0][8]=&end_time[0][8]=&action_type[0][8]=0&start_time[0][9]=&end_time[0][9]=&action_type[0][9]=0&start_time[0][10]=&end_time[0][10]=&action_type[0][10]=0&start_time[0][11]=12:00&end_time[0][11]=14:00&action_type[0][11]=2&start_time[1][0]=&end_time[1][0]=&action_type[1][0]=0&start_time[1][1]=&end_time[1][1]=&action_type[1][1]=0&start_time[1][2]=&end_time[1][2]=&action_type[1][2]=0&start_time[1][3]=&end_time[1][3]=&action_type[1][3]=0&start_time[1][4]=&end_time[1][4]=&action_type[1][4]=0&start_time[1][5]=&end_time[1][5]=&action_type[1][5]=0&start_time[1][6]=&end_time[1][6]=&action_type[1][6]=0&start_time[1][7]=&end_time[1][7]=&action_type[1][7]=0&start_time[1][8]=&end_time[1][8]=&action_type[1][8]=0&start_time[1][9]=&end_time[1][9]=&action_type[1][9]=0&start_time[1][10]=&end_time[1][10]=&action_type[1][10]=0&start_time[1][11]=&end_time[1][11]=&action_type[1][11]=0&start_time[2][0]=&end_time[2][0]=&action_type[2][0]=0&start_time[2][1]=&end_time[2][1]=&action_type[2][1]=0&start_time[2][2]=&end_time[2][2]=&action_type[2][2]=0&start_time[2][3]=&end_time[2][3]=&action_type[2][3]=0&start_time[2][4]=&end_time[2][4]=&action_type[2][4]=0&start_time[2][5]=&end_time[2][5]=&action_type[2][5]=0&start_time[2][6]=&end_time[2][6]=&action_type[2][6]=0&start_time[2][7]=&end_time[2][7]=&action_type[2][7]=0&start_time[2][8]=&end_time[2][8]=&action_type[2][8]=0&start_time[2][9]=&end_time[2][9]=&action_type[2][9]=0&start_time[2][10]=&end_time[2][10]=&action_type[2][10]=0&start_time[2][11]=&end_time[2][11]=&action_type[2][11]=0&start_time[3][0]=&end_time[3][0]=&action_type[3][0]=0&start_time[3][1]=&end_time[3][1]=&action_type[3][1]=0&start_time[3][2]=&end_time[3][2]=&action_type[3][2]=0&start_time[3][3]=&end_time[3][3]=&action_type[3][3]=0&start_time[3][4]=&end_time[3][4]=&action_type[3][4]=0&start_time[3][5]=&end_time[3][5]=&action_type[3][5]=0&start_time[3][6]=&end_time[3][6]=&action_type[3][6]=0&start_time[3][7]=&end_time[3][7]=&action_type[3][7]=0&start_time[3][8]=&end_time[3][8]=&action_type[3][8]=0&start_time[3][9]=&end_time[3][9]=&action_type[3][9]=0&start_time[3][10]=&end_time[3][10]=&action_type[3][10]=0&start_time[3][11]=&end_time[3][11]=&action_type[3][11]=0&start_time[4][0]=&end_time[4][0]=&action_type[4][0]=0&start_time[4][1]=&end_time[4][1]=&action_type[4][1]=0&start_time[4][2]=&end_time[4][2]=&action_type[4][2]=0&start_time[4][3]=&end_time[4][3]=&action_type[4][3]=0&start_time[4][4]=&end_time[4][4]=&action_type[4][4]=0&start_time[4][5]=&end_time[4][5]=&action_type[4][5]=0&start_time[4][6]=&end_time[4][6]=&action_type[4][6]=0&start_time[4][7]=&end_time[4][7]=&action_type[4][7]=0&start_time[4][8]=&end_time[4][8]=&action_type[4][8]=0&start_time[4][9]=&end_time[4][9]=&action_type[4][9]=0&start_time[4][10]=&end_time[4][10]=&action_type[4][10]=0&start_time[5][0]=&end_time[5][0]=&action_type[5][0]=0&start_time[5][1]=&end_time[5][1]=&action_type[5][1]=0&start_time[5][2]=&end_time[5][2]=&action_type[5][2]=0&start_time[5][3]=</p></div><div data-bbox=)

```

&end_time[5][3]=&action_type[5][3]=0&start_time[5][4]=&end_time[5][4]=&action_type[5][4]=
0&start_time[5][5]=&end_time[5][5]=&action_type[5][5]=0&start_time[5][6]=&end_time[5][6]=
&action_type[5][6]=0&start_time[5][7]=&end_time[5][7]=&action_type[5][7]=0&start_time[5][8]
=&end_time[5][8]=&action_type[5][8]=0&start_time[5][9]=&end_time[5][9]=&action_type[5][9]
=0&start_time[5][10]=&end_time[5][10]=&action_type[5][10]=0&start_time[5][11]=&end_time[
5][11]=&action_type[5][11]=0&start_time[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_t
ime[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_t
ype[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_t
ime[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_
time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_
type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_
time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0
&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]
=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][
2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][
3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][
5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7]
[7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7]
[8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7]
[10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0

```

Parameter			Values	Description	
8xschedule_day	12xschedule_item	start_time	struct	start_time : start rec time [char [32]]	
		end_time		end_time : end rec time [char [32]]	
		action_type		action_type : rec type [integer]	
ch		integer	Channel id		
event		integer	Smart event type 0:region entarnce 1:region exiting 2:advanced.motion detection 3:tamper detection 4:line crossing 5:loitering 6:human detection 7:people counting		
interval		integer	Triggered Interval(s)		

Example: get schedule parametes

http://192.168.9.147/sdk.cgi?action=get.schedule.vca_email_sched&ch=0&event=0

Example: set schedule vca email sched parametes

[http://192.168.9.147/sdk.cgi?action=set.schedule.vca_email_sched&ch=0&event=0&interval=20&&start_time\[0\]\[0\]=00:00&end_time\[0\]\[0\]=24:00&action_type\[0\]\[0\]=8&start_time\[0\]\[1\]=00:00&end_time\[0\]\[1\]=12:00&action_type\[0\]\[1\]=1&start_time\[0\]\[2\]=&end_time\[0\]\[2\]=&action_type\[0\]\[2\]=0&start_time\[0\]\[3\]=&end_time\[0\]\[3\]=&action_type\[0\]\[3\]=0&start_time\[0\]\[4\]=&end_time\[0\]\[4\]=&action_type\[0\]\[4\]=0&start_time\[0\]\[5\]=&end_time\[0\]\[5\]=&action_type\[0\]\[5\]=0&start_time\[0\]\[6\]=&end_time\[0\]\[6\]=&action_type\[0\]\[6\]=0&start_time\[0\]\[7\]=&end_time\[0\]\[7\]=&action_type\[0\]\[7\]=0&start_time\[0\]\[8\]=&end_time\[0\]\[8\]=&action_type\[0\]\[8\]=0&start_time\[0\]\[9\]=&end_time\[0\]\[9\]=&action_type\[0\]\[9\]=0&start_time\[0\]\[10\]=&end_time\[0\]\[10\]=&action_type\[0\]\[10\]=0&start_time\[0\]\[11\]=&end_time\[0\]\[11\]=&action_type\[0\]\[11\]=0](http://192.168.9.147/sdk.cgi?action=set.schedule.vca_email_sched&ch=0&event=0&interval=20&&start_time[0][0]=00:00&end_time[0][0]=24:00&action_type[0][0]=8&start_time[0][1]=00:00&end_time[0][1]=12:00&action_type[0][1]=1&start_time[0][2]=&end_time[0][2]=&action_type[0][2]=0&start_time[0][3]=&end_time[0][3]=&action_type[0][3]=0&start_time[0][4]=&end_time[0][4]=&action_type[0][4]=0&start_time[0][5]=&end_time[0][5]=&action_type[0][5]=0&start_time[0][6]=&end_time[0][6]=&action_type[0][6]=0&start_time[0][7]=&end_time[0][7]=&action_type[0][7]=0&start_time[0][8]=&end_time[0][8]=&action_type[0][8]=0&start_time[0][9]=&end_time[0][9]=&action_type[0][9]=0&start_time[0][10]=&end_time[0][10]=&action_type[0][10]=0&start_time[0][11]=&end_time[0][11]=&action_type[0][11]=0)


```
_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter	Values	Description
ch	integer	Channel id
triAlarms	integer	triAlarms:Alarm Input rec
triChannels	char	triChannels:Trigger Channel rec [char [64]]
event	integer	Smart event type 0:region entarnce 1:region exiting 2:advanced.motion detection 3:tamper detection 4:line crossing 5:loitering 6:human detection 7:people counting

Example: set schedule var alarm output parameters

http://192.168.9.147/sdk.cgi?action=get.schedule.vca_others&ch=0&event=0

Example: set schedule var_alarm_output parameters

http://192.168.9.147/sdk.cgi?action=set.schedule.vca_others&ch=0&event=0&triAlarms=63&triChannels=11111111111111111111111111111111

1.6 PLAYBACK

Parameter	Values	Description
time	long	Start time available
chnid	integer	Channel ID
stream	integer	Stream type (0=main stream,1=sub stream)
dayinfo	String max 31	A month information (no_record=0,exit_record =1)

Example: get event parameters

<http://192.168.9.129/sdk.cgi?action=get.playback.pbdayinfo&time=2016-03-07 00:00:00&chnid=1&stream=0>

Parameter	Values	Description
chnid	integer	Channel ID
stream	integer	Stream type (0=main stream,1=sub stream)
startTime	string max 31	Start time string
endTime	string max 31	End time string
cnt	integer max 100	Record count
sid	interger	Play back Session ID
startTime	string max 31	Start time string
endTime	string max 31	end time string
recordType	integer	0 : NONE 1<<0 : Timing 1<<1 : motion detect 1<<2 : alarm in 1<<3 : manual 1<<4 : anr 1<<5 : vca

Example: get event parametes

<http://192.168.9.129/sdk.cgi?action=get.playback.recordinfo&chnid=0&stream=0&startTime=2018-08-13%2000:00:00&endTime=2018-08-13%2023:59:59>

Parameter	Values	Description
sid	interger	Play back Session ID
page	interger	Page Number
cnt	interger max 100	Record count
startTime	string max 31	Start time string
endTime	string max 31	End time string
recordType	integer	0 : NONE 1<<0 : Timing 1<<1 : motion detect 1<<2 : alarm in 1<<3 : manual 1<<4 : anr 1<<5 : vca

Example: get event parametes

http://192.168.9.129/sdk.cgi?action=get.playback.recordinfo_page&sid=0&page=2

Parameter	Values	Description
sid	interger	Session ID
real_time	String max 32	Play time
except	interger	exception

Example: get event parametes

<http://192.168.9.129/sdk.cgi?action=get.playback.remote&chans=0&time=2016-03-07%2012:00:00>

Parameter	Values	Description
sessionId	integer	Session ID
jumpTime	String max 32	Jump time string

Example: get playback jump

<http://192.168.9.129/sdk.cgi?action=get.playback.jump&sessionId=1&jumpTime=2016-03-06>

06:44:33

Parameter	Values	Description
cnt	integer	Session ID count
sid	integer	Session ID
jumpTime	String max 32	Jump time string

Example: get playback jump batch

[http://192.168.9.129/sdk.cgi?action=get.playback.jump_batch&cnt=3&sid\[0\]=0&sid\[1\]=1&sid\[2\]=2&jumpTime=2018-08-12 05:23:25](http://192.168.9.129/sdk.cgi?action=get.playback.jump_batch&cnt=3&sid[0]=0&sid[1]=1&sid[2]=2&jumpTime=2018-08-12 05:23:25)

Parameter	Values	Description
sec	long	timestamp
curPlayTime	String max 32	

Example: get playback playtime

<http://192.168.9.129/sdk.cgi?action=get.playback.playtime&sid=1>

Parameter	Values	Description
sid	integer	Play back session ID
port	integer	RTSP Port
respath	String max 128	RTSP resource path

Example: get playback rtsp url

<http://192.168.9.129/sdk.cgi?action=get.playback.rtspurl&sid=1>

To set playback pause parameters

Example: set playback pause

<http://192.168.9.129/sdk.cgi?action=set.playback.pause&sid=1>

Parameter	Values	Description
cnt	integer	Play back session count
sid	integer	Play back session ID

Example: set playback pause batch

[http://192.168.9.129/sdk.cgi?action=set.playback.pause_batch&cnt=3&sid\[0\]=0&sid\[1\]=1&sid\[2\]=2](http://192.168.9.129/sdk.cgi?action=set.playback.pause_batch&cnt=3&sid[0]=0&sid[1]=1&sid[2]=2)

Parameter	Values	Description
res	String max 32	If channel n is successfully snapshot, res[n]=0, otherwise failed.

Example: set playback snapshot

<http://192.168.9.129/sdk.cgi?action=set.playback.snapshot&chnid=1>

To set playback snapshot save parametes

Example: set playback snapshot save

`http://192.168.9.129/sdk.cgi?action=set.playback.snapshot_save&disk=/media/sd1`

To set playback resume parametes

Example: set playback resume

`http://192.168.9.129/sdk.cgi?action=set.playback.resume&sid=1`

Parameter	Values	Description
chnid	integer	Channel ID
sid	integer	Play back Session ID
startTime	string	Start time string
endTime	string	End time string
playTime	string	Play time string

Example: set playback start

`http://192.168.9.129/sdk.cgi?action=set.playback.start&set.playback.start&chnid=2&sid=0&start
Time=2018-08-16 00:00:00&endTime=2018-08-16 23:59:59&playTime=2018-08-16 10:13:40`

To set playback step parametes

Example: set playback step

`http://192.168.9.129/sdk.cgi?action=set.playback.step&sid=1&direct=0`

To set playback step parametes

Example: set playback step batch

`http://192.168.9.129/sdk.cgi?action=set.playback.step_batch&direct=0&cnt=3&sid[0]=0&sid[1]=
1&sid[2]=2`

To set playback stop parametes

Example: set playback stop

`http://192.168.9.129/sdk.cgi?action=set.playback.stop&sid=1`

To set playback stop parametes

Example: set playback stop batch

`http://192.168.9.129/sdk.cgi?action=set.playback.stop_batch&cnt=3&sid[0]=0&sid[1]=1&sid[2]=
2&close=0`

To set playback speed parametes

Example: set playback speed

<http://192.168.9.129/sdk.cgi?action=set.playback.speed&sid=1&direct=0&speed=2>

To set playback speed parametes

Example: set playback speed batch

[http://192.168.9.129/sdk.cgi?action=set.playback.speed_batch&cnt=3&sid\[0\]=0&sid\[1\]=1&sid\[2\]=2&speed=1](http://192.168.9.129/sdk.cgi?action=set.playback.speed_batch&cnt=3&sid[0]=0&sid[1]=1&sid[2]=2&speed=1)

To set playback close parametes

Example: set playback close

<http://192.168.9.129/sdk.cgi?action=set.playback.close&sid=1>

To set playback close parametes

Example: set playback close batch

[http://192.168.9.129/sdk.cgi?action=set.playback.close_batch&cnt=3&sid\[0\]=0&sid\[1\]=1&sid\[2\]=2](http://192.168.9.129/sdk.cgi?action=set.playback.close_batch&cnt=3&sid[0]=0&sid[1]=1&sid[2]=2)

1.7 CAMERA

Parameter	Values		Description
ret	integer		0 : success -1 : fail
chnid	integer		Channel id
struct ipc_param_range main_range	24xres	width	width : integer
		height	height : integer
	framerate_max		framerate_max : integer
	framerate_min		framerate_min : integer
	bitrate_max		bitrate_max : integer
	bitrate_min		bitrate_min : integer
	vcodec_type		vcodec_type: integer
	cur_res	width	framerate : integer
		height	bitrate : integer
	framerate		
struct ipc_param_range sub_range	24xres	width	width : integer
		height	height : integer
	framerate_max		framerate_max : integer
	framerate_min		framerate_min : integer
	bitrate_max		bitrate_max : integer
	bitrate_min		bitrate_min : integer
	Vcodec_type		vcodec_type: integer
	cur_res	width	framerate : integer
		height	bitrate : integer
	framerate		

sub_enable	Boolean	Enable sub streamer 0 : disable 1 : enable
audio_enable	Boolean	Enable audio 0 : disable 1 : enable
SmartStreamSupport	Boolean	Support smart stream 0 : nonsupport 1 : support
SmartStream	Boolean	Enable main smart stream 0 : disable 1 : enable
SmartStreamLevel	integer	Range 1~10
SubSmartStream	Boolean	Enable sub smart stream 0 : disable 1 : enable
SubSmartStreamLevel	integer	Range 1~10

Example: get camera parametes

<http://192.168.9.129/sdk.cgi?action=get.camera.ipcparam&chnid=1>

To set camera ipcparam parametes

Example: set camera ipcparam parametes

<http://192.168.9.129/sdk.cgi?action=set.camera.ipcparam&chnid=0&mainFramerate=24&mainBitrate=4096&IframeInterval=20&subIframeInterval=50&subEnable=1&subFramerate=25&subBitrate=512&audioEnable=0&mainVideoType=0&videoTypeEnable=1&subVideoType=0&SmartStreamSupport=1&SmartStream=0&SmartStreamLevel=3&SubSmartStream=0&SubSmartStreamLevel=2&mainResWidth=1920&mainResHeight=1080&subResWidth=704&subResHeight=576>

Parameter	Values	Description
chanid	integer	Channel ID
port	integer	IP Camera port
protocol	integer	IP Camera protocol
state	integer	IP Camera state -2 : no_resource -1 : disconnect 0 : null 1 : waiting 2 : connect
main_rtsp_port	integer	Main RTSP port(554)
ipaddr	String max 32	IP address
manufacturer	String max 64	Manufacturer
hwid	String max 128	Hardware ID
sn	String max 128	Serial number
fwversion	String max 64	Firmware version
mac	String max 48	MAC
model	String max 64	Model
model_id	integer	0 : onvif 1 : rtsp

		2 : canon
mrespath	String max 128	Main streamer path
srespath	String max 128	Sub streamer path
main_rtspurl	String max 128	Main URL
sub_rtspurl	String max 128	Sub URL

Example: get camera parametes

<http://192.168.9.129/sdk.cgi?action=get.camera.ipclist>

To add camera channel parametes

Example: add camera channel parametes

http://192.168.9.129/sdk.cgi?action=add.camera.channel&id=1&name=CAM2&enable=1&ip_addr=192.168.9.126&manage_port=80&camera_protocol=0&name=CAM2&username=admin&password=ms1234&sub_rtsp_enable=1&sync_time=0&transmit_protocol=&poe_channel=&physical_port=&mac_addr=

To modify camera channel parametes

Example: modify camera channel parametes

http://192.168.9.129/sdk.cgi?action=modify.camera.channel&id=1&name=CAM3&enable=1&ip_addr=192.168.9.126&manage_port=80&camera_protocol=0&name=CAM2&username=admin&password=ms1234&sub_rtsp_enable=1&sync_time=0&transmit_protocol=

To remove camera channel parametes

Example: remove camera channel parametes

<http://192.168.9.129/sdk.cgi?action=remove.camera.channel&chnid=1>

Parameter	Values	Description
pro_id	integer	Protocol id
pro_name	String max 64	Protocol name
function	integer	Function value
enable	boolean	Enable protocol 0 : disable 1 : enable
display_model	boolean	Display 0 : dispaly 1 : nodisplay

Example: get camera parametes

<http://192.168.9.129/sdk.cgi?action=get.camera.protocol>

Parameter	Values	Description
ipaddr	String max 32	IP Camera address
mac	String max 32	MAC

port	integer	Port
protocol	integer	Protocol 0 : onvif 1 : rtsp 2 : milesight 3 : canon 4 : psia
manufacturer	String max 64	manufatuer
hwid	String max 128	Hardware ID
sn	String max 128	Serial number
fwversion	String max 64	Firmware version
model	String max 64	0 : onvif 1 : rtsp 2 : canon
model_id	integer	Model ID
netmask	String max 32	netmask
dns	String max 32	dns
gateway	String max 32	gateway

Example: get camera parametes

http://192.168.9.129/sdk.cgi?action=search.camera.chns&pro_id=0

To test camera ip conflict parametes

Example: test camera ip conflict parametes

<http://192.168.9.129/sdk.cgi?action=test.camera.ipconflict&ip=192.168.9.127>

To test camera ip conflict parametes

Example: test camera ipc connenct

<http://192.168.9.129/sdk.cgi?action=test.camera.ipcconn&ip=192.168.9.126&port=80&user=admin&password=1111&protocol=0&model=0>

To get camera irtsp info parametes

Example: get camera ipc connenct

<http://192.168.9.129/sdk.cgi?action=get.camera.rtsp>

Parameter	Values	Description
chanid	integer	Channel id
brightness	integer	
contrast	integer	
saturation	integer	
result	integer	result

Example: get camera imageparam

<http://192.168.9.129/sdk.cgi?action=get.camera.imageparam&chnid=0>

To set camera imageparam info parametes

Example: set camera imageparam

<http://192.168.9.129/sdk.cgi?action=set.camera.imageparam&chnid=0&brightness=127&contrast=127&saturation=127>

Parameter		Values	Description
ch	integer	Channel id	
4xPrivacy_mask	area_id	struct	area_id: privacy_mask area id [integer]
	enable		enable: [integer]
	start_x		start_x:set start x [integer]
	start_y		start_y:set start y [integer]
	area_width		area_width:privacy_mask area width [integer]
	area_height		area_height:privacy_mask area height [integer]
	screen_width		screen_width:[integer] 480
	screen_height		screen_height:[integer] 270
	fill_color		fill_color:privacy_mask color [integer]

Example: get camera privacy_mask

http://192.168.9.147/sdk.cgi?action=get.camera.privacy_mask&chnid=0

To set camera iprivity_mask parametes

Example: set camera privacy_mask

[http://192.168.9.147/sdk.cgi?action=set.camera.privacy_mask&ch=0&area_id\[0\]=0&enable\[0\]=1&start_x\[0\]=55&start_y\[0\]=44&area_width\[0\]=91&area_height\[0\]=60&screen_width\[0\]=480&screen_height\[0\]=270&fill_color\[0\]=0&area_id\[1\]=1&enable\[1\]=1&start_x\[1\]=213&start_y\[1\]=60&area_width\[1\]=105&area_height\[1\]=80&screen_width\[1\]=480&screen_height\[1\]=270&fill_color\[1\]=0&area_id\[2\]=2&enable\[2\]=1&start_x\[2\]=74&start_y\[2\]=155&area_width\[2\]=76&area_height\[2\]=56&screen_width\[2\]=480&screen_height\[2\]=270&fill_color\[2\]=0&area_id\[3\]=3&enable\[3\]=1&start_x\[3\]=252&start_y\[3\]=174&area_width\[3\]=120&area_height\[3\]=80&screen_width\[3\]=480&screen_height\[3\]=270&fill_color\[3\]=0](http://192.168.9.147/sdk.cgi?action=set.camera.privacy_mask&ch=0&area_id[0]=0&enable[0]=1&start_x[0]=55&start_y[0]=44&area_width[0]=91&area_height[0]=60&screen_width[0]=480&screen_height[0]=270&fill_color[0]=0&area_id[1]=1&enable[1]=1&start_x[1]=213&start_y[1]=60&area_width[1]=105&area_height[1]=80&screen_width[1]=480&screen_height[1]=270&fill_color[1]=0&area_id[2]=2&enable[2]=1&start_x[2]=74&start_y[2]=155&area_width[2]=76&area_height[2]=56&screen_width[2]=480&screen_height[2]=270&fill_color[2]=0&area_id[3]=3&enable[3]=1&start_x[3]=252&start_y[3]=174&area_width[3]=120&area_height[3]=80&screen_width[3]=480&screen_height[3]=270&fill_color[3]=0)

Parameter		Values	Description
ip	String max 32		
port	integer		
user	String max 64		
password	String max 32		
ret	integer	result	

Example: try camera connectoin

<http://192.168.9.147/sdk.cgi?action=test.try.camera.ipcconn&ip=192.168.10.234&port=80&user=admin&password=1234&protocol=0>

Parameter		Values	Description
chnid	integer	Channel id	
smartir	integer	Smart IR	
whiteblance	integer	White Balance	

focusmode	integer	
antiblurry	integer	
wdrenable	integer	Wide Dynamic Range
wdrlevel	integer	Wide Dynamic Level
wdrstarthour	integer	Start Time
wdrstartminute	integer	Start Time
wdrstophour	integer	End Time
wdrstopminute	integer	End Time
regiontype	integer	
hlcmode	integer	High Light Compensation
exclude	integer	
exposemode	integer	
modelType	integer	
exposeregion	String max 64	

Example: get camera enhance

<http://192.168.9.147/sdk.cgi?action=get.camera.ipcimage.enhance&chnid=0>

To set camera enhance parametes

Example: set camera enhance

<http://192.168.9.150/sdk.cgi?action=set.camera.ipcimage.enhance&chnid=0&smartir=0&whitebalance=0&wdrenable=0&wdrlevel=2&wdrstarthour=6&wdrstartminute=0&wdrstophour=18&wdrstopminute=0&hlcmode=0>

Parameter	Values	Description
chnid	integer	Channel id
colorkiller	integer	Day/Night Mode
modestarthour	integer	Start time of Nigh
modestartminute	integer	Start time of Nigh
modestophour	integer	End time of Night
modestopminute	integer	End time of Night
exposurectrl	integer	Power Line Frequency
lighttype	integer	
mirctrl	integer	Video Orientation
localdisplay	integer	
ircutaddaytonight	integer	
ircutadnighttoday	integer	
corridormode	integer	Corridor Mode
imagerotation	integer	Image Rotation
saveCorridor	integer	If saveCorridor=0 save mirctrl, If saveCorridor=1 save corridormode & imagerotation

Example: get camera display

<http://192.168.9.147/sdk.cgi?action=get.camera.ipcimage.display&chnid=0>

To set camera display parametes

Example: set camera display

<http://192.168.9.147/sdk.cgi?action=set.camera.ipcimage.display&chnid=0&colorkiller=2&modestarthour=18&modestartminute=0&modestophour=6&modestopminute=0&exposurectrl=1&mirctrl=-1&ircutaddaytonight=303&ircutadnighttoday=451&corridormode=0&imagerotation=0&savCorridor=0>

Parameter	Values	Description
ret_cnt	integer	Channel num
Chnid(array)	integer	Channel id
model(array)	integer	Channel model
fwversion(array)	integer	Channel firmware version

Example: get camera model info

<http://192.168.9.147/sdk.cgi?action=get.camera.all.modelinfo>

To set camera fisheye mode

Example: set camera fisheye mode

<http://192.168.9.129/sdk.cgi?action=set.camera.fisheye.mode&chnid=1&fishmount=1&fishdisplay=4>

Parameter	Values	Description
chnid	integer	Channel id
fishmount	integer	Fishmount mode
fishdisplay	integer	displaymode

Example: get camera fisheye mode

<http://192.168.9.147/sdk.cgi?action=get.camera.fisheye.mode&chnid=1>

Parameter	Values	Description
chnid	integer	Channel id

Example: get camera type

<http://192.168.9.129/sdk.cgi?action=get.camera.ipctype&chnid=0>

Parameter	Values	Description
chnid	integer	Channel id
type	integer	0:All streams 1:Primary stream 2:Secondary stream
enable_text	boolean	Enable show main video title 0 : disable 1 : enable
text_name	String max 32	Main video title
textpos	integer	select main title position 0:Top-Left 1:Top-Right 2:Bottom-Left

		3:Bottom-Right
enable_date	integer	Enable show main date 0 : disable 1 : enable
datepos	integer	select main date position 0:Top-Left 1:Top-Right 2:Bottom-Left 3:Bottom-Right
dateformat	integer	select main date format 0:YYYY-MM-DD 1:MM-DD-YYYY 2:DD-MM-YYYY
enable_text_sub	boolean	Enable show sub video title 0 : disable 1 : enable
text_name_sub	String max 32	Sub video title
textpos_sub	integer	select subtitle position 0:Top-Left 1:Top-Right 2:Bottom-Left 3:Bottom-Right
enable_date_sub	integer	Enable show sub date 0 : disable 1 : enable
datepos_sub	integer	select sub date position 0:Top-Left 1:Top-Right 2:Bottom-Left 3:Bottom-Right
dateformat_sub		select sub date format 0:YYYY-MM-DD 1:MM-DD-YYYY 2:DD-MM-YYYY

Example: get osd info

<http://192.168.9.129/sdk.cgi?action=get.camera.osd&chnid=0>

To set camera osd info

Example: set camera osd info

http://192.168.2.134/sdk.cgi?action=set.camera.osd&type=1&chnid=0&enable_text=1&text_na me=main_test&textpos=0&enable_date=1&datepos=1&dateformat=2&enable_text_sub=1&text _name_sub=sub test&textpos_sub=0&enable_date_sub=1&datepos_sub=1&dateformat_sub=2

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
region	String 300	Region area 0:disable 1:enable

Example: get vca region entarnce info



<http://192.168.9.129/sdk.cgi?action=get.camera.vca.region.entarnce&chnid=0>

Example: set vca region entarnce info

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
region	String 300	Region area 0:disable 1:enable

Example: get vca region exiting info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.region.exiting&chnid=0>

Example: set vca region exiting info

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
sensitivity	integer	Sensitivity:1-10
region	String 300	Region area 0:disable 1:enable

Example: get vca advanced motion info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.advanced.motion&chnid=0>

Example: set vca advanced motion info

Parameter	Values	Description
chanid	integer	Channel ID

enable	integer	0:disable 1:enable
sensitivity	integer	Sensitivity:1-10

Example: get vca tamper detection info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.tamper.detection&chnid=0>

Example: set vca tamper detection info

<http://192.168.9.129/sdk.cgi?action=set.camera.vca.tamper.detection&chnid=0&enable=1&sensitivity=9>

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
width	integer	Width
height	integer	Height
startX	integer	X of start point
StartY	integer	Y of start point
stopX	integer	X of stop point
stopY	integer	Y of stop point
direction	integer	Direction of line 0:A->B 1:B->A 2:A<->B

Example: get vca line crossing info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.line.crossing&chnid=0>

Example: set vca line crossing info

<http://192.168.9.129/sdk.cgi?action=set.camera.vca.line.crossing&chnid=0&enable=1&startX0=1518&startY0=972&stopX0=1482&stopY0=121&direction0=0&startX1=0&startY1=0&stopX1=0&stopY1=0&direction1=0&startX2=0&startY2=0&stopX2=0&stopY2=0&direction2=0&startX3=10&startY3=10&stopX3=1&stopY3=1&direction3=3>

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
minLoiteringTime	integer	Min loitering time(3-300s)
loiteringObjectSize	integer	Object size (1-100)
region	String 300	Region area 0:disable 1:enable

Example: get vca loitering info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.loitering&chnid=0>

Example: set vca loitering info

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
tracks	integer	Tracks 0:disable 1:enable

Example: get vca human detection info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.human.detection&chnid=0>

Example: set vca human detection info

http://192.168.9.129/sdk.cgi?action=set.camera.vca.human.detection&chnid=0&enable=1&track_s=1

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
width	integer	Width
height	integer	Height
startX	integer	X of start point
StartY	integer	Y of start point
stopX	integer	X of stop point
stopY	integer	Y of stop point
osdEnable	integer	Show counting OSD 0:disable 1:enable
osdTextPosition	integer	Text position 0:Top-Left 1:Top-Right 2:Bottom-Left 3:Bottom-Right
fontSize	integer	Font Size 0:Smallest 1:Small 2:Medium 3:Large 4:Largest 5:Auto
triggerEnable	integer	Enable Alarm 0:disable

		1:enable
triggerEnableByIn	integer	
inThresholds	integer	
triggerEnableByOut	integer	
outThresholds	integer	
triggerEnableBySum	integer	
sumThresholds	integer	

Example: get vca people counting info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.people.counting&chnid=0>

Example: set vca people counting info

<http://192.168.9.129/sdk.cgi?action=set.camera.vca.people.counting&chnid=0&enable=1&startX=10&startY=10&stopX=300&stopY=100&osdEnable=1&osdTextPosition=0&fontSize=0&triggerEnable=0&triggerEnableByIn=0&inThresholds=1&triggerEnableByOut=0&outThresholds=1&triggerEnableBySum=0&sumThresholds=1>

Parameter	Values	Description
chanid	integer	Channel ID
enable	integer	0:disable 1:enable
width	integer	Width
height	integer	Height
processFps	integer	Process FPS
scenarioMode	integer	Scenario Mode 0:Outdoor 1:Indoor
cameraInstallation	integer	Camera Installation 0:Horizontal View 1:Overhead View 2:Angle View
analysisType	integer	Analysis Type 2:Standard 3:Advanced
minObjectX	integer	Start point x of min object
minObjectY	integer	Start point y of min object
minObjectWidth	integer	Width of min object
minObjectHeight	integer	Height of min object
maxObjectX	integer	Start point x of max object
maxObjectY	integer	Start point y of max object
maxObjectWidth	integer	Width of max object
maxObjectHeight	integer	Height of max object

Example: get vca settings info

<http://192.168.9.129/sdk.cgi?action=get.camera.vca.settings&chnid=0>

Example: set vca settings info

```
http://192.168.9.129/sdk.cgi?action=set.camera.vca.settings&processFps=5&scenarioMode=0&cameraInstallation=2&analysisType=2&minObjectX=10&minObjectY=10&minObjectWidth=100&minObjectHeight=100&maxObjectX=50&maxObjectY=50&maxObjectWidth=200&maxObjectHeight=200
```

Parameter	Values	Description
chanid	integer	Channel ID
licenseStatus	integer	License status 0:Invalid 1:valid
license	String	License

Example: get vca licence info

```
http://192.168.9.129/sdk.cgi?action=get.camera.vca.licence&chnid=0
```

Example: set vca licence info

```
http://192.168.9.129/sdk.cgi?action=set.camera.vca.licence&license=yzyJ32xhuECumunnFFGGH  
Hhhiyl
```

Parameter	Values	Description
chanid	integer	Channel ID

Example: set vca clearcount info

```
http://192.168.9.129/sdk.cgi?action=set.camera.vca.clearcount&chnid=0
```

Parameter	Values	Description
chanid	integer	Channel ID
support	integer	Support 0:no 1:yes

Example: get vca support info

```
http://192.168.9.129/sdk.cgi?action=get.camera.vca.support&chnid=0
```

Parameter	Values	Description
support	string	Support 0:no 1:yes

Example: get vca support all info

```
http://192.168.9.129/sdk.cgi?action=get.camera.vca.support_all
```

Parameter	Values	Description
chanid	integer	Channel ID

enable	integer	0:disable 1:enable
width	integer	Width
height	integer	Height
person_point_cnt	integer	Point count
id	integer	Point id
type	integer	Point type
startX	integer	Start point x
startY	integer	Start point y
stopX	integer	Stop point x
stopY	integer	Stop point y

Example: get vca person point info

http://192.168.9.129/sdk.cgi?action=get.camera.vca.person_point&chnid=0

1.8 STATUS.

Parameter	Values	Description
chanid	integer	Channel ID
port	integer	IP Camera port
protocol	integer	IP Camera protocol
state	integer	IP Camera state -2 : no_resource -1 : disconnect 0 : null 1 : waiting 2 : connect
main_rtsp_port	integer	Main RTSP port(554)
ipaddr	String max 32	IP address
manufacturer	String max 64	Manufacturer
hwid	String max 128	Hardware ID
sn	String max 128	Serial number
fwversion	String max 64	Firmware version
mac	String max 48	MAC
model	String max 64	Model
model_id	integer	0 : onvif 1 : rtsp 2 : canon
mrespath	String max 128	Main streamer path
srespath	String max 128	Sub streamer path
main_rtspurl	String max 128	Main URL
sub_rtspurl	String max 128	Sub URL

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.allipc>

Parameter	Values	Description
-----------	--------	-------------

chanid	integer	Channel ID
port	integer	IP Camera port
protocol	integer	IP Camera protocol
state	integer	IP Camera state -2 : no_resource -1 : disconnect 0 : null 1 : waiting 2 : connect
main_rtsp_port	integer	Main RTSP port(554)
ipaddr	String max 32	IP address
manufacturer	String max 64	Manufacturer
hwid	String max 128	Hardware ID
sn	String max 128	Serial number
fwversion	String max 64	Firmware version
mac	String max 48	MAC
model	String max 64	Model
model_id	integer	0 : onvif 1 : rtsp 2 : canon
mrespath	String max 128	Main streamer path
srespath	String max 128	Sub streamer path
main_rtspurl	String max 128	Main URL
sub_rtspurl	String max 128	Sub URL

Example: get status parameters

<http://192.168.9.129/sdk.cgi?action=get.status.ipcinfo&ch=0>

Parameter		Values		Description	
main	cur_res	width	integer		
		height	integer		
	frame_rate		integer		
	bit_rate		integer		
	connection		integer		
	sub	cur_res	width	integer	
			height	integer	
		frame_rate		integer	
		bit_rate		integer	
		connection		integer	
		record		integer	
alarm		integer			
chnid		integer			

Example: get status parameters

<http://192.168.9.129/sdk.cgi?action=get.status.ipcstatus>

Parameter		Values	Description
video_loss		Long long	Bit mask, each bit represent a channel

<code>motion_detect</code>	Long long	Similar as above
<code>alarm_out</code>	integer	Alarm out bit mask
<code>alarm_in</code>	sensor	Sensor bit mask
<code>regionin_detect</code>	Long long	Bit mask, each bit represent a channel
<code>regionexit_detect</code>	Long long	Bit mask, each bit represent a channel
<code>advanced_motion_detect</code>	Long long	Bit mask, each bit represent a channel
<code>tamper_detect</code>	Long long	Bit mask, each bit represent a channel
<code>linecross_detect</code>	Long long	Bit mask, each bit represent a channel
<code>loiter_detect</code>	Long long	Bit mask, each bit represent a channel
<code>human_detect</code>	Long long	Bit mask, each bit represent a channel
<code>in</code>	integer	People count of in
<code>out</code>	integer	People count of out

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.event>

Parameter	Values	Description
<code>alarm</code>	integer	Result of io alarm status

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.ioalarm>

Parameter	Values	Description
<code>sensor</code>	integer	Result of io sensor status

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.iosensor>

Parameter	Values	Description
<code>total</code>	integer	Total bandwidth
<code>free</code>	integer	Free bandwidth
<code>used</code>	integer	Used bandwidth

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.netbandwidth>

Parameter	Values	Description
<code>ifname</code>	String max 10	Lan1/Lan2/Bond0
<code>netif_id</code>	integer	Network card ID
<code>conn_stat</code>	integer	Connected Saturation 0 : unconnected 1 : connected
<code>speed_mode</code>	integer	Speed mode 10M/s 100M/s
<code>duplex</code>	integer	Duplex 0 : Half-duplex 1 : ful-duplex

enable	Boolean	Enable 0 : disable 1 : enable
dhcp_enable	Boolean	Enable 0 : disable 1 : enable
ip	String max 24	IP address
mac	String max 24	MAC
primary_dns	String max 24	Preferred DNS
second_dns	String max 24	Alternate DNS
gateway	String max 24	Gateway
netmask	String max 24	Net mask
mtu	integer	MTU(B)
ret_cnt	integer	Get status netinfo result count

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.netinfo>

Parameter	Values	Description
ifname	String max 10	Network Card Name LAN1/LAN2/BOND0
rx_speed	integer	Receive Rate(Unit:Bps)
tx_speed	integer	Send Rate(Unit: Bps)
netif_id	integer	Network Card ID

Example: get status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.netspeed>

Example: get motion status parametes

<http://192.168.9.129/sdk.cgi?action=get.status.motion>

1.9 RECORD

Parameter	Values	Description
ch	Integer 0~15	Channel id
mode	integer	Record mode 0 : Never 1 : Always 2 : By Schedule
audio_on	boolean	Enable audio 0 : disable 1 : enable
prev_rec_on	boolean	Enable pre-record 0 : disable 1 : enable
prev_rec_duration	Integer 0~10s	Pre-record time(s)
post_rec_on	boolean	Enable post-record 0 : disable 1 : enable
post_rec_duration	Integer 1~60 min	Post-record time(min)
rec_expiration_date	Integer	Expiration date record (day)

	0~60 day	
photo_expiration_date	Integer	Photo expiration time(day) 0:unlimit other:days

Example: get record parametes

<http://192.168.9.129/sdk.cgi?action=get.record.advanced&id=0>

To set record advanced parametes

Example: set record advanced

http://192.168.9.129/sdk.cgi?action=set.record.advanced&id=0&mode=2&audio_enable=0&prev_record_on=1&prev_record_duration=10&post_record_on=1&post_record_duration=3&record_expiration_date=0

To set record parametes

Example: set record record parametes

<http://192.168.9.129/sdk.cgi?action=set.record.record&chnid=0&enable=0&event=1>

To set record mode parametes

Example: set record mode

<http://192.168.9.129/sdk.cgi?action=set.record.mode&id=0&mode=0>

Parameter		Values	Description
8xschedule_day	12xschedule_item	start_time	start_time : start rec time [char [32]] end_time : end rec time [char [32]] action_type : rec type [integer] Wholeday_enable : 0/1 [integer] Wholeday_action_type : wholeday action type [integer]
		end_time	
		action_type	
	wholeday_enable		
		wholeday_action_type	
	enable	integer	~
ch		integer	Channel id

Example: get record schedule

<http://192.168.9.129/sdk.cgi?action=get.record.schedule&ch=0>

To set schedule recsched parametes

Example: set schedule recsched parametes

[http://192.168.9.129/sdk.cgi?action=set.record.schedule&ch=0&enable=1&wholeday_enable\[0\]=1&wholeday_action_type\[0\]=1&start_time\[0\]\[0\]=00:00&end_time\[0\]\[0\]=01:00&action_type\[0\]\[0\]=0&start_time\[0\]\[1\]=00:00&end_time\[0\]\[1\]=12:00&action_type\[0\]\[1\]=1&start_time\[0\]\[2\]=&end_time\[0\]\[2\]=&action_type\[0\]\[2\]=0&start_time\[0\]\[3\]=&end_time\[0\]\[3\]=&action_type\[0\]\[3\]=0&start_time\[0\]\[4\]=&end_time\[0\]\[4\]=&action_type\[0\]\[4\]=0&start_time\[0\]\[5\]=&end_time\[0\]\[5\]=&](http://192.168.9.129/sdk.cgi?action=set.record.schedule&ch=0&enable=1&wholeday_enable[0]=1&wholeday_action_type[0]=1&start_time[0][0]=00:00&end_time[0][0]=01:00&action_type[0][0]=0&start_time[0][1]=00:00&end_time[0][1]=12:00&action_type[0][1]=1&start_time[0][2]=&end_time[0][2]=&action_type[0][2]=0&start_time[0][3]=&end_time[0][3]=&action_type[0][3]=0&start_time[0][4]=&end_time[0][4]=&action_type[0][4]=0&start_time[0][5]=&end_time[0][5]=&)


```
me[6][0]=&end_time[6][0]=&action_type[6][0]=0&start_time[6][1]=&end_time[6][1]=&action_type[6][1]=0&start_time[6][2]=&end_time[6][2]=&action_type[6][2]=0&start_time[6][3]=&end_time[6][3]=&action_type[6][3]=0&start_time[6][4]=&end_time[6][4]=&action_type[6][4]=0&start_time[6][5]=&end_time[6][5]=&action_type[6][5]=0&start_time[6][6]=&end_time[6][6]=&action_type[6][6]=0&start_time[6][7]=&end_time[6][7]=&action_type[6][7]=0&start_time[6][8]=&end_time[6][8]=&action_type[6][8]=0&start_time[6][9]=&end_time[6][9]=&action_type[6][9]=0&start_time[6][10]=&end_time[6][10]=&action_type[6][10]=0&start_time[6][11]=&end_time[6][11]=&action_type[6][11]=0&wholeday_enable[7]=0&wholeday_action_type[7]=0&start_time[7][0]=&end_time[7][0]=&action_type[7][0]=0&start_time[7][1]=&end_time[7][1]=&action_type[7][1]=0&start_time[7][2]=&end_time[7][2]=&action_type[7][2]=0&start_time[7][3]=&end_time[7][3]=&action_type[7][3]=0&start_time[7][4]=&end_time[7][4]=&action_type[7][4]=0&start_time[7][5]=&end_time[7][5]=&action_type[7][5]=0&start_time[7][6]=&end_time[7][6]=&action_type[7][6]=0&start_time[7][7]=&end_time[7][7]=&action_type[7][7]=0&start_time[7][8]=&end_time[7][8]=&action_type[7][8]=0&start_time[7][9]=&end_time[7][9]=&action_type[7][9]=0&start_time[7][10]=&end_time[7][10]=&action_type[7][10]=0&start_time[7][11]=&end_time[7][11]=&action_type[7][11]=0
```

Parameter	Values	Description
record	char	Batch setting reord start [char[64]]
stop	char	Batch setting reord stop [char[64]]

Example: set camera batchsetting

1.10 PTZ

To set ptz auto focus parameters

Example: set ptz auto focus parameters

http://192.168.9.129/sdk.cgi?action=set.ptz.auto_focus&chanid=1

To set ptz auto scan parameters

Example: set ptz auto scan parameters

http://192.168.9.129/sdk.cgi?action=set.ptz.auto_scan&chanid=1

To set ptz brush off parameters

Example: set ptz brush off parameters

http://192.168.9.129/sdk.cgi?action=set.ptz.brush_off&chanid=1

To set ptz brush on parameters

Example: set ptz brush on parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.brush_on&chanid=

To set ptz down parametes

Example: set ptz down parametes

<http://192.168.9.129/sdk.cgi?action=set.ptz.down&chanid=&speed=>

To set ptz focus in parametes

Example: set ptz focus in parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.focus_in&chanid=&speed=

To set ptz focus out parametes

Example: set ptz focus out parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.focus_out&chanid=&speed=

To set ptz focus stop parametes

Example: set ptz focus stop parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.focus_stop&chanid=

Parameter	Values	Description
id	integer	Channel id
baudrate	boolean	PTZ baudrate
data_bit	An unsigned integer	Data bit
stop_bit	An unsigned integer	Stop bid
parity_type	integer	Parity type 0 : none 1 : Even 2 : Odd
protocol	integer	PTZ Protocol
address	Integer 1~255	PTZ address
com_type	integer	
connect_type	integer	Connect type 0 : onvif 1 : RS485

To set ptz iris minus parametes

Example: set ptz iris minus parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.iris_minus&chanid=

To set ptz iris plus parametes

Example: set ptz iris plus parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.iris_plus&chanid=

To set ptz left parametes

Example: set ptz left parametes

<http://192.168.9.129/sdk.cgi?action=set.ptz.left&chanid=&speed=>

To set ptz left down parametes

Example: set ptz left down parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.left_down&chanid=&pan=&tilt=

To set ptz left up parametes

Example: set ptz left up parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.left_up&chanid=&pan=&tilt=

To set ptz light off parametes

Example: set ptz light off parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.light_off&chanid=

To set ptz light on parametes

Example: set ptz light on parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.light_on&chanid=

To set ptz preset clear parametes

Example: set ptz preset clear parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.preset_clear&chanid=&preno=

To set ptz preset goto parametes

Example: set ptz preset goto parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.preset_goto&chanid=&preno=

To set ptz preset set parametes

Example: set ptz preset set parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.preset_set&chanid=&preno=

To set ptz right parametes

Example: set ptz right parametes

<http://192.168.9.129/sdk.cgi?action=set.ptz.right&chanid=&speed=>

To set ptz right down parametes

Example: set ptz right down parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.right_down&chanid=&pan=&tilt=

To set ptz right up parametes

Example: set ptz right up parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.right_up&chanid=&pan=&tilt=

To set ptz serial port parametes

Example: set ptz serial port parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.serial_port&id=0&baudrate=9600&date_bit=8&stop_bit=1&parity_type=0&protocol=8&address=1&com_type=0&connect_type=0

To set ptz stop parametes

Example: set ptz stop parametes

<http://192.168.9.129/sdk.cgi?action=set.ptz.stop&chanid=>

To set ptz tour add parametes

Example: set ptz tour add parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_add&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

To set ptz tour clear parametes

Example: set ptz tour clear parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_clear&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

To set ptz tour delete parametes

Example: set ptz tour delete parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_delete&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

spd=&tour_time=

To set ptz tour down parametes

Example: set ptz tour down parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_down&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

To set ptz tour run parametes

Example: set ptz tour run parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_run&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

To set ptz tour stop parametes

Example: set ptz tour stop parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_stop&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

To set ptz tour up parametes

Example: set ptz tour up parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.tour_up&chanid=&tourid=&key=&preno=&tour_spd=&tour_time=

To set ptz up parametes

Example: set ptz up parametes

<http://192.168.9.129/sdk.cgi?action=set.ptz.up&chanid=&speed=>

To set ptz zoom in parametes

Example: set ptz zoom in parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.zoom_in&chanid=&speed=

To set ptz zoom out parametes

Example: set ptz zoom out parametes

http://192.168.9.129/sdk.cgi?action=set.ptz.zoom_out&chanid=&speed=

1.11 DISK

To set disk format parametes

Example: set disk format parametes

<http://192.168.9.129/sdk.cgi?action=set.disk.format&diskid=1>

Parameter	Values	Description
ret_cnt	integer	
port	integer	
vendor	String max 32	
total	integer	
user	integer	
free	integer	
state	integer	0=disk no be format 1=disk is OK, has be formatted 2=disk is not exist 3=disk is formatting 4=disk has error, may be can not be used. 5=loading
hddtype	integer	0=unknow 1=local 2=usb 3=nas 4=raid 5=esata 6=ipsan 7=global spare 8=in raid 9=none
property	integer	0=read only 1=R/W
raid_status	integer	1=disk no exist in system 2=disk not be used for raid array 3=disk used for a raid array 4=disk used for a raid array,but only for spare/resync/recovery function 5=disk exist in a raid array, bug has error, can not be used. 6=disk has be removed
raid_level	integer	
raid_task	integer	
raid_diskcnt	integer	

Example: get disk storage info parametes

http://192.168.9.129/sdk.cgi?action=get.disk.storage_info

To set disk storage info parametes

Example: set disk storage info parametes

http://192.168.9.129/sdk.cgi?action=set.disk.storage_info&portId=1&recycle_mode=0

Parameter	Values	Description
-----------	--------	-------------

portId	integer	
property	integer	0=read-only,1=r/w

To set disk storage property parametes

Example: set disk storage property parametes

<http://192.168.9.129/sdk.cgi?action=set.disk.property&portId=1&property=1>

Parameter	Values	Description
portId	integer	
type	integer	

To set disk storage delete parametes

Example: set disk storage delete parametes

<http://192.168.9.129/sdk.cgi?action=set.disk.delete&portId=2&type=3>

Parameter	Values	Description
mode	integer	Recycle mode 0=disable 1=enable

To set disk storage recycle mode parametes

Example: set disk storage recycle mode parametes

http://192.168.9.129/sdk.cgi?action=set.disk.recycle_mode&mode=0

To get disk storage recycle mode parametes

Example: set disk storage recycle mode parametes

http://192.168.9.129/sdk.cgi?action=get.disk.recycle_mode

1.12 QT

To control qt

Url:

<http://ip/sdk.cgi?action=set.qtctrl.cmd&cmd=XXXXX>

Example:

To LiveView

http://192.168.9.150/sdk.cgi?action=set.qtctrl.cmd&cmd=Page_LiveView

Parameter	Values	Description
result	String max 20	
curPage	String max 20	
live_view_wnd_num	integer	
play_back_wnd_num	integer	

live_view_select_wnd	integer	
play_back_select_wnd	integer	
live_viewFullScreenWnd	integer	
play_back_fullScreenWnd	integer	
playbackspeed	String max 10	
playbackmode	String max 20	
playbackdate	String max 20	
playbacktime	String max 20	

Cmd	Action	Description
Page_XXXX	Go to other page	Page_LiveView, Page_PlayBack
FullScreen	FullScreen	
PlayBack_NextHour	Next hour	
PlayBack_LastHour	Last hour	
PlayBack_SpeedUp	Fast forward	
PlayBack_Rewind	Rewind	
PlayBack_LastDay	Last day	
PlayBack_NextDay	Next day	
PlayBack_LastMonth	Last month	
PlayBack_NextMonth	Next month	
PlayBack_Play	Play	
PlayBack_Pause	Pause	
PlayBack_Stop	Stop	
Wnd_X	Split screen	Wnd_4, Wnd_9, Wnd16
SelChannel_XX	Select channel	SelChannel_0, SelChannel_12 (0-15)
SelWnd_CENTER	Select window	
SelWnd_UP	Select window	
SelWnd_DOWN	Select window	
SelWnd_LEFT	Select window	
SelWnd_RIGHT	Select window	
SelWnd_XX	Select the wnd	SelWnd_9
Audio	Open or close audio	
SingleChannel_XX	Full the certain channel	
ChangeFocus_Next	Foucs the next item	
Menu	Call the menu	
Esc	Return live view page	
Seq_XX	Open or close sequence	Seq_Main Seq_Sub Seq_Current

